





























## DJELOVI NAMOTAČA KONCA - ONDERDELEN VOOR SPOELWINDERS - PIÈCES POUR BOBINEUS PARTS FOR BOBBIN WINDERS - TEILE FÜR SPULER

 <p><b>Ref : 382822-451</b> Bobbin winder rod Singer 770-775-778</p> <p><b>077.382.822</b></p>	 <p><b>Ref : 382326</b> Bobbin winder rod Singer 900-900/3-920/3-925-1200-2000-2001-2005-2010</p> <p><b>077.382.326</b></p>	 <p><b>Ref : 445827-451</b> Bobbin winder rod Singer 600-603-604-620-620E-625-626-628-629-630-630E-635-636-638-639-640E-645-646-648E-649</p> <p><b>077.445.827</b></p>
 <p><b>Ref : 163788</b> Actuating cam Singer 646-737-750-755-756-758</p> <p><b>077.163.788</b></p>	 <p><b>Ref : 382820</b> Actuating cam Singer 737-750-755-756-758-770-775-778</p> <p><b>077.382.820</b></p>	 <p><b>Ref : 381504 = 381958</b> Bobbin winder cam Singer 900/3-920/3-925-935U-960-2000-2010</p> <p><b>077.381.504</b></p>
 <p><b>Ref : 313956</b> Actuating lever Singer 4610-46134617-4623-6234-6235-6267-6268-9113-9117-9124-9133-9137-9143-9217-9224-9240-9416-9430-9900-9440</p> <p><b>077.313.956</b></p>	 <p><b>Ref : 181563-900</b> Lifter bracket Singer 900/3-920-920/3-925-1022-1200-2000-2001-2005-2010</p> <p><b>077.181.563</b></p>	 <p><b>Ref : 125365</b> Bobbin winder spring Singer 15-88, 15-91, 200-2, 1200-1</p> <p><b>077.125.365</b></p>
 <p><b>Ref : 15291</b> Spring stop latch Singer 66-6, 99-13</p> <p><b>077.015.291</b></p>	 <p><b>Ref : 163641</b> Stop latch spring Singer 774-776</p> <p><b>077.163.641</b></p>	 <p><b>Ref : 15366</b> Thread guide spring Singer 66-6</p> <p><b>077.015.366</b></p>
 <p><b>Ref : 312897</b> Bobbin winder spring Singer 4610-6233-6234-6235-9410</p> <p><b>077.312.897</b></p>	 <p><b>Ref : 125395</b> Tension bed Singer 15-91</p> <p><b>077.125.395</b></p>	 <p><b>Ref : 320.236.20</b> Bobbin winder hub Bernina 730-732-740-750-800-801-801S-802S-803S-807-808-809-810-811-817-819-830-831</p> <p><b>077.320.236</b></p>
 <p><b>Ref : 408612</b> Bobbin winder hub Singer 935U</p> <p><b>077.408.612</b></p>	 <p><b>Ref : 44365-891 = 352241</b> Bobbin winder stopper Singer fits most models</p> <p><b>077.044.365</b></p>	 <p><b>Ref : 531766</b> Bobbin winder spring Singer 2302-2303-2304-2315-2330-2440-2502-2503-2504-2515-2530-2950-3314-3317-3343-5705-5812-5814-5816-5818-FM17</p> <p><b>077.531.766</b></p>
 <p><b>Ref : 312897</b> Bobbin winder spring Singer 4610-6233-6234-6235-9410</p> <p><b>077.312.897</b></p>	 <p><b>Ref : XA9548051</b> Bobbin winder spring plate Babylock ESG Ellageo Brother ULT2001-ULT2002</p> <p><b>077.954.805</b></p>	 <p><b>Ref : XA9545051</b> Bobbin winder spring Babylock ESG Brother ULT2001, ULT2002</p> <p><b>077.095.450</b></p>
 <p><b>Ref : X59939021</b> Bobbin winder spring Babylock B15, B17, B21, BL6200, BL6700 Brother LS1217, LS1520, LS2125, LS2720, LS2725, LS2820, LS2825, LS2920, PS1000, PS1250, PS1800, PS1950, PS2100, RS15, RS25, RS35, VX1120, VX1125, VX1140, XL5010, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, PX100, PX150, PX200, PX300</p> <p><b>077.059.939</b></p>	 <p><b>Ref : 172552</b> Bobbin winder spring Singer 401-401A-403-500-500A-503</p> <p><b>077.172.552</b></p>	
 <p><b>Ref : X52102051</b> Bobbin winder spring Babylock BL1556, BL2100, BL2150, BL2160, BL6000, BL9500, ESI, ESI2 Brother XL4010, XL4020, XL4030, XL4050, XL4060, XL4040, PC5000, PC6000, PC7000, PC7500, PC8000, PC8895, PS1700, PS1750, PS1900, XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200</p> <p><b>077.052.102</b></p>	 <p><b>Ref : 172555</b> Bobbin winder spring Singer 401-403</p> <p><b>077.172.555</b></p>	
 <p><b>Ref : 4117067-01</b> Bobbin winder spring Husqvarna S105-S110-S120-S140-S150-S160-S180-S185-S190</p> <p><b>077.411.067</b></p>	 <p><b>Ref : E1A2065000</b> Bobbin winder thread guide Singer 7350</p> <p><b>077.206.500</b></p>	 <p><b>Ref : X54336051</b> Thread guide bobbin winder Brother XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XR29, XR23</p> <p><b>077.054.336</b></p>

## DJELOVI NAMOTA A KONCA - ONDERDELEN VOOR SPOELWINDERS - PIECES POUR BOBINEUS PARTS FOR BOBBIN WINDERS - TEILE FÜR SPULER



**Ref : 130894001** Thread guide  
Babylock BL1550  
Brother 7029, PS1200, VX1010,  
VX1020, VX1120, VX1125, VX1140,  
VX707, VX710, VX760, VX780,  
VX800, VX807, VX809, VX810,  
VX880, VX890, VX920, VX940,  
VX950, VX970, VX980, VX1100,  
VX1200  
**077.130.894**



**Ref : 172259**  
Thread guide bobbin  
winder tension bracket  
Singer 247-248  
**077.172.259**



**Ref : XA9797051**  
Bobbin winder thread  
guide plate  
Babylock ESG Ellageo  
Brother ULT2001-  
ULT2002  
**077.979.705**



**Ref : 445924**  
Bobbin winder stopper  
Singer 2302-2303-2304-2315-2330-  
2440-2502-2503-2504-2505-2515-  
2517-2530-2543-3270-3314-3317-  
3343-5605-5610-5705-5710-5812-  
5814-5816-5818-5825-5830-5838-  
6011-6012-57825-CM17-DX14-FM17-  
FM22-SM14  
**077.445.924**



**Ref : 320.252.031**  
Bobbin winder stopper  
Bernina  
**077.320.252**



**Ref : 0018667001**  
Bobbin winder stopper  
Bernina 1006-1630  
**077.001.866**



**Ref : BWS653-8**  
Bobbin winder stopper  
Brother 320-360-451-461-661-  
741-751-761-XL851-XL1351-  
XL1561-1681-XL1781-XL711-  
XL781-XL791-681  
Fits most Taiwan machines  
**077.006.538**



**Ref : 357718-900**  
Bobbin winder stopper  
Singer 2950-5417-5430  
**077.357.718**



**Ref : XA9530051**  
Bobbin winder holder  
Babylock ESG Ellageo  
Brother ULT2001-  
ULT2002  
**077.953.005**



**Ref : XA9541051**  
Bobbin winder presser  
guide assembly  
Babylock ESG Ellageo  
Brother ULT2001-ULT2002  
**077.954.105**



**Ref : XA9540001**  
Bobbin winder presser  
Babylock ESG Ellageo  
Brother ULT2001-ULT2002  
**077.954.000**



**Ref : X50532051**  
Bobbin winder plate  
presser  
Babylock ESG Ellageo  
Brother ULT2001,  
ULT2002  
**077.505.320**



**Ref : 0018437101**  
Bobbin winder spindle  
Bernina 130, 140, 150, 160,  
190  
**077.018.437**



**Ref : 4113919-01**  
Bobbin winder spindle  
Husqvarna 6640  
**077.411.391**



**Ref : 366671**  
Bobbin winder spring  
Brother 320-461-761-7029-  
PS1200-VX1010-VX1020-  
VX707-VX710-VX760-  
VX780-VX920-VX940-  
VX950-VX970-VX980-XL711  
**077.366.671**



**Ref : 320.228.03**  
Bobbin winder hub  
Bernina 900, 910, 930  
**077.320.228**



**Ref : X56202001**  
Bobbin winder  
Babylock BL9500-ESI-ESI2-EMI1-  
EMI2-Espree  
Bernina Deco 500, Deco 600  
Brother PC5000-PC6000-PC7000-  
PC7500-PC8000-PC8895-PE100-  
PE150-PE180D-PE200  
**077.562.020**



**Ref : XA9549151**  
Bobbin winder tension  
guide assembly  
Babylock ESG Ellageo  
Brother ULT2001-  
ULT2002  
**077.954.915**



**Ref : XC4672051**  
Bobbin winder base  
Babylock BLCC-BLDC-  
BLQC  
Brother NX200-NX400-  
NX600  
**077.467.205**



**Ref : XC7912051**  
Bobbin winder base  
Babylock BLG (Ellegante),  
BLG2 (Ellegante 2)  
Brother NV4000D  
**077.791.205**



**Ref : 387830**  
Bobbin winder felt  
Singer Quantum XL5000,  
Quantum XL6000  
**077.387.830**



**Ref : X50831001**  
Bobbin winder switch  
Brother 7029-VX920-  
VX940-VX950-VX970-  
VX980  
**077.508.310**



**Ref : BWG-6**  
Bobbin winder gear  
Riccar RW-6, RW-7, RL613,  
RL624, RL624E, RL634DE,  
RL634E, RL724E, RL739DE  
& RL749L  
**077.000.006**



**Ref : 6587**  
Bobbin winder spring  
White 2220, 2221, 2222  
**077.006.587**



**Ref : 98-695545-01**  
Stop  
Pfaff 280, 290, 70, 80, 90  
**077.695.545**