














## DRŽAČI IGALA - PINCES AIGUILLES - **BABYLOCK** - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : SG-F12-00A = 4TW-4102-01A</b> Needle bar w/ clamp Babylock BL80, BL90, BL5180, BL5260, BL4-428, BL4-428D, BL4-728, BL4-728D, BL4-736D, BL4-838D, BLSE200 <b>077.010.042</b></p>	 <p><b>Ref : SNZ1 = 36353 = SNZ6</b> Needle clamp with screw Babylock BL500, BL1000, BL1050, BL1400, BL2000, BL2200, BL2800 Kenmore 158.10401, 158.12312, 158.13400, 158.14510, 158.17530, 158.13402 Necchi 538, 539, 3204FB Riccar 469FA, 900, 925, 1900, 1925, 800R, R1500, R1570, R1570FB, R1800, R1850, R250, R7620, RE640 Singer 5102, 5107, 5122, 5123, 5124, 5127 White 202, 208, 219, 310, 423, 447, 505, 510, 639, 644, 645, 646, 690, 710, 734, 793, 954, 967, 1418, 1760, 4040, 4075 <b>077.300.760</b></p>	 <p><b>Ref : X55185001</b> Needle bar &amp; clamp Babylock EM2 Bernina Deco 600 Brother PE150-PE180D-PE200 <b>077.055.185</b></p>
 <p><b>Ref : SNZ11</b> Babylock BL1400 Riccar 469FA <b>077.300.763</b></p>	 <p><b>Ref : X53896001</b> Babylock BL9500, ESI, ESI2 Brother PC5000-PC6000-PC7000-PC7500-PC8000-PC8895-PS1900 <b>077.053.896</b></p>	 <p><b>Ref : XA6035001</b> Pin needle clamp Babylock ESN (Encore)-ESE-ESE2-ESG-ESG2-ESG3-ESP (Espire) Brother PC2800-PC3000-PC6500-PC8200-PC8500-ULT2001-ULT2002D-ULT2003D <b>078.006.035</b></p>
 <p><b>Ref : X58769001</b> Babylock EMI1 Bernina Deco 500 Brother PE100 <b>077.058.769</b></p>	 <p><b>Ref : XA1849101=XA1849151 =XA1849201</b> Needle bar &amp; clamp Babylock ESN (Encore)-ESL-ESE-ESE2-ESG-ESG2-ESG3-ESP (Espire) Brother PC2800-PC3000-PC6500-PC8200-PC8500-ULT2001-ULT2002D-ULT2003D <b>077.001.849</b></p>	 <p><b>Ref : XC3554051</b> Babylock BLG (Ellegante), BLG2 (Ellegante 2), INT (Intrigue) Brother CS8100, CS8200, NV4000D, CS8060, CS8150, NV500D, SE270D <b>077.003.554</b></p>
 <p><b>Ref : XC2427001 = XC2427031 = XC2427051</b> Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY (Melody), BLN (Esante), BLL, BLR, BLSO (Ellisimo), BLTP (Tempo) Brother BM2600, BM3500, L25, L35, LS-590, NX200, NX400, NX600, SE350, XL2120, XL2121, XL2130, XL2140, XL2150, XL2220, XL2230, XL2240, XL2250, XL2600, XL2610, XL2620, XL3500, XL3500T, XL3510, XL3520, XL3800 <b>077.002.427</b></p>	 <p><b>Ref : XZ0001051=XZ0001151=XZ0001121</b> Needle clamp body Babylock B15, B17, B21, BL37, BL6300, BL6800 Brother PX100, PX150, PX200, PX300, RS15, RS25, RS35, XL5010, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XL6040, XL6050, XL6060, XL6452, XL6562, XR46, XR52C, XR65T <b>077.000.105</b></p>	 <p><b>Ref : 801506008 = 102047008 = 395711-35 = X54859051 = 129627001</b> Needle clamp &amp; screw Babylock BL1550 - BL1556 - Brother VX808 - VX809 Elna 1010-2002-2004-2006-2100-2300-3003FS-3005-3007 Janome 105-106-108-3125-352-353-370-372-373-470-533-556-562-591-592-605-620-625FA-640-641-642-Jem Gold 660-663-669-670-671-672-674-676-692-792-844-900-910-920-980-990-1004-1506-1508-1518-1612-1622-1803-1804-1814-1818-1822-5001-JA1500-RE3000-S650-S750-SR2000-SR2100-TB12 Kenmore 385.15616500 Pfaff 204-205-206-207-208-209-210-211-521-541-721-741 <b>077.801.506</b></p>
 <p><b>Ref : 125161100</b> Needle clamp guide Babylock BL1556, BL2160, BL7500, BL8000, BL8500, BL9500, ESI, ESI2, BL6200, BL2100, BL6000, BL2150, BL6700 Brother 845, XL4010, XL4020, XL4030, XL4050, XL4060, 7029, XL4040, PC5000, PC6000, PC7000, PC7500, PC8000, PS1000, PS1200, PS1250, PS1700, PS1750, PS1800, PS1900, PS1950, PS2100, PS2200, PS2300, PS2500, VX1010, VX1020, VX800, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200, PC8895 <b>77.125.161</b></p>		

## DRŽAČI IGALA - PINCES AIGUILLES - **BERNINA** - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 0011687000</b> Bernina 1020-1030-1031 <b>077.001.687</b></p>	 <p><b>Ref : 0065197000</b> Bernina 1000-1000+-1001-1004-1005-1006-1008-1010-1011-1015-1020-1030-1031-1090-1120-1130-1230-1260-1530-1630 <b>077.006.519</b></p>	 <p><b>Ref : 0068687100</b> Bernina 940-950 <b>077.006.868</b></p>
 <p><b>Ref : 0082087001</b> Needle clamp w/ bar Bernina 120-125-130-135-140-145-150-153-155-160-163-165-170-180-185-200 <b>077.008.208</b></p>	 <p><b>Ref : 304.002.54</b> Bernina 530-534-540-640/2-700-701-707-708-709-710-717-729-730-732-740-750-807-808-809-810-811-817-819-830-831-832-840-850-900 <b>077.304.002</b></p>	 <p><b>Ref : X55185001</b> Needle bar &amp; clamp Babylock EM2 Bernina Deco 600 Brother PE150-PE180D-PE200 <b>077.055.185</b></p>
 <p><b>Ref : X58769001</b> Needle bar Babylock EMI1 Bernina Deco 500 Brother PE100 <b>077.058.769</b></p>	 <p><b>Ref : X75205-001</b> Bernina 800 Brother 730DE-760DE-900D-929D-934D-920D-PL1050-640D-925D-935D-929D-1034D Husqvarna 900-560ED <b>077.075.205</b></p>	 <p><b>Ref : 304.247.14</b> Needle clamp w/ screw Bernina 801-910-930-931-932-801S-802S-803S <b>077.304.247</b></p>

## DRŽAČI IGALA - PINCES AIGUILLES - BROTHER - NEEDLE CLAMPS - NADELKLAMMERN



**Ref : 125161100** - Needle clamp guide

Babylock BL1556, BL2160, BL7500, BL8000, BL8500, BL9500, ESI, ESI2, BL6200, BL2100, BL6000, BL2150, BL6700  
 Brother 845, XL4010, XL4020, XL4030, XL4050, XL4060, 7029, XL4040, PC5000, PC6000, PC7000, PC7500, PC8000, PS1000,  
 PS1200, PS1250, PS1700, PS1750, PS1800, PS1900, PS1950, PS2100, PS2200, PS2500, VX1010, VX1020, VX800, VX809,  
 VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XL3010, XL3022,  
 XL3025, XL3027, XL3030, XL3100, XL3200, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200, PC8895

**077.125.161**



**Ref : 129853001** - Needle clamp with screw

Babylock BL1556, BL2160, BL7500, BL8000, BL8500, BL6200, BL2100, BL6000, BL2150, BL6700, BL7000  
 Brother 320, 461, 761, 845, XL4010, XL4020, XL4030, XL4050, XL4060, 7029, XL4040, PS1000, PS1200, PS1250, PS1700, PS1750, PS1800, PS1950, PS2100, VX1010, VX1020,  
 VX520, VX540, VX560, VX620, VX640, VX660, VX707, VX710, VX760, VX780, VX800, VX807, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, XL2010, XL2015,  
 XL2021, XL2022, XL2025, XL2030, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XL711, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200  
 Janome Schoolmate S-3015

Singer 3001, 3002, 3003, 3004, 3005, 3011, 3012, 3013, 3014, 4001, 4002, 4005, 4006, 4009, 4011, 4012, 4015, 4016, 4019, 4022, 5502, 5504, 5505, 5508, 5522, 5524, 5525, 5528

**077.129.853**



**Ref : X53896001**

Babylock BL9500, ESI,  
 ESI2  
 Brother PC5000-PC6000-  
 PC7000-PC7500-PC8000-  
 PC8895-PS1900

**077.053.896**



**Ref : X55185001**

Needle bar & clamp  
 Babylock EM2  
 Bernina Deco 600  
 Brother PE150-PE180D-  
 PE200

**077.055.185**

**Ref : X57282051**

Brother PS2200, PS2300,  
 PS2500

**077.057.282**

**Ref : X58769001**

Babylock EMI1  
 Bernina Deco 500  
 Brother PE100

**077.058.769**

**Ref : X75205-001**

Bernina 800  
 Brother 730DE-760DE-900D-  
 929D-934D-920D-PL1050-  
 640D-925D-935D-929D-  
 1034D  
 Husqvarna 900-560ED

**077.075.205**

**Ref : X75650-001**

Needle bar  
 Brother 546-546D-626D-  
 640D-834DP-920D-934D-  
 PL1050

**077.075.650**

**Ref : X76510-001**

Needle bar  
 Brother PL1500-PL2000-  
 PL1600-925D-935D-929D-  
 1034D

**077.076.510**

**Ref : X76514-001**

Brother PL1500

**077.076.514**



**Ref : X80880001**

Brother PQ1300, PQ1500

**077.080.880**



**Ref : XA0643151**

Brother LS1217-LS1520-  
 LS2125-LS2720-LS2725-  
 LS2820-LS2825-LS2920-  
 VX1120-VX1125-VX1140

**077.006.431**



**Ref : XA1849101=XA1849151**  
**=XA1849201**

Needle bar & clamp  
 Babylock ESN (Encore)-ESL-ESE-  
 ESE2-ESG-ESG2-ESG3-ESP  
 (Espire)  
 Brother PC2800-PC3000-PC6500-  
 PC8200-PC8500-ULT2001-  
 ULT2002D-ULT2003D

**077.001.849**

**Ref : XA5129251**

Brother PE300S, PE400D

**077.005.129**



**Ref : XA5718051** Needle clamp pin

Babylock B15, B17, B21, BL37, BL6300, BL6800  
 Brother PX100, PX150, PX200, PX300, RS15, RS25, RS35, XL5010, XL5011,  
 XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060,  
 XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600,  
 XL5700, XL6040, XL6050, XL6060, XL6452, XL6562, XR46

**077.005.718**



**Ref : XA5779001**

Needle clamp pin  
 Brother PE300S, PE400D

**077.005.779**



**Ref : XA6035001**

Pin needle clamp  
 Babylock ESN (Encore)-ESE-  
 ESE2-ESG-ESG2-ESG3-ESP  
 (Espire)  
 Brother PC2800-PC3000-PC6500-  
 PC8200-PC8500-ULT2001-  
 ULT2002D-ULT2003D

**078.006.035**



**Ref : XB0302-001**

Needle clamp  
 Brother 929D

**077.000.302**

**Ref : XC2423051**

Needle bar  
 Brother NX200, NX400,  
 NX600

**077.002.423**



**Ref : XC2426020**

Needle clamp plate  
 Brother CS8060, CS8100,  
 CS8150, CS8200,  
 NV500D, SE270D

**077.002.426**



**Ref : XC2427001 = XC2427031=XC2427051**

Needle clamp

Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BLCC (Crafter's Choice), BLCC2  
 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY (Melody), BLN (Esante),  
 BLL, BLR, BLSO (Ellisimo) & BLTP (Tempo)  
 Brother BM2600, BM3500, L25, L35, LS-590, NX200, NX400, NX600, SE350, XL2120,  
 XL2121, XL2130, XL2140, XL2150, XL2220, XL2230, XL2240, XL2250, XL2600,  
 XL2610, XL2620, XL3500, XL3500T, XL3510, XL3520, XL3800

**077.002.427**



**Ref : XC3554051**

Babylock BLG (Ellegante),  
 BLG2 (Ellegante 2), INT  
 (Intrigue)  
 Brother CS8100, CS8200,  
 NV4000D, CS8060, CS8150,  
 NV500D, SE270D

**077.003.554**

**Ref : XC4162021**

Needle Block support  
 Babylock INT (Intrigue), BLG  
 (Ellegante), BLG2 (Ellegante 2)  
 Brother CS8060, CS8100,  
 CS8150, CS8200, NV4000D

**077.004.162**



**Ref : XC8560131 =**

**XD1219031 = XC8560031**  
 Needle clamp with bar  
 Brother CE4000, CS100,  
 CS4000, CS6000, EX660

**077.008.560**

## DRŽAĆI IGALA - PINCES AIGUILLES - **BROTHER** - NEEDLE CLAMPS - NADELKLAMMERN



**Ref : XZ0001051 = XZ0001151 = XZ0001121**

Needle clamp body

Babylock B15, B17, B21, BL37, BL6300, BL6800

Brother PX100, PX150, PX200, PX300, RS15, RS25, RS35, XL5010, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XL6040, XL6050, XL6060, XL6452, XL6562, XR46, XR52C, XR65T

**077.000.105**



**Ref : 2054** Needle clamp, Universal

Brother 360, 451, 661, 681, 741, 751, 1681, XL781, XL791, XL851, XL1351, XL1561, XL1781

Janome 125, 366, 443, 444, 445, 446, 447, 495, 507, 508, 509, 510, 532, 534, 535, 543, 545, 548, 551, 575, 586, 589

Necchi 537, 2216, 2416, 2716, BU Nova

Riccar 608, REC5900, SZ702

Singer 27, 127, 128, 15CL, 185 (185J), 15-30, 15-86, 15-96, 15-97, 15-87, 66-6, 99-13

**077.002.054**

## DRŽAĆI IGALA - PINCES AIGUILLES - **ELNA** - NEEDLE CLAMPS - NADELKLAMMERN

**Ref : 13068-T**

Elna 300, 1500, 1600

Riccar REC6000

**077.013.068**



**Ref : 395727-22**

Elna 6003, 6004

**077.395.727**



**Ref : 411242-40**

Elna Star 11, Star 13, Lotus 14, Stella 17, Star 21, Lotus 22, Star 23, Lotus 24, Stella 27, Star 31, Lotus 32, Star 33, Lotus 34, Lotus 35, Lotus 36, Stella 37, Air Electronic 38, Air Electronic 39, Star 41, Carina Jubilee 45, Carina Jubilee 46, Lotus 52, Carina Jubilee 55, Stella 57, Air Electronic 58, Air Electronic 59, Star 64, Carina Jubilee 65, Carina Jubilee 66, Air Electronic 68, Air Electronic 69, Star 72, Star 74, Carina Jubilee 500, Star 62, Carina Jubilee 56, Star 43

**077.411.242**



**Ref : 462801-20**

Needle clamp with screw  
Elna 5000-6000-7000-8000-9000-Club-Diva

**077.462.801**



**Ref : 801506008 = 102047008 = 395711-35 = X54859051 = 129627001** Needle clamp & screw

Babylock BL1550 - BL1556

Brother VX808 - VX809

Elna 1010-2002-2004-2006-2100-2300-3003FS-3005-3007

Janome 105-106-108-3125-352-353-370-372-373-470-533-556-562-591-592-605-620-625FA-640-641-642-Jem Gold 660-663-669-670-671-672-674-676-692-792-844-900-910-920-980-990-1004-1506-1508-1518-1612-1622-1803-1804-1814-1818-1822-5001-JA1500-RE3000-S650-S750-SR2000-SR2100-TB12

Kenmore 385.15616500

Pfaff 204-205-206-207-208-209-210-211-521-541-721-741

**077.801.506**



**Ref : 822661007**

Needle clamp

Janome 659, 2014, 2015, 2018, 2022, 2030, 2122, 2200, 3000, 3015, 3023, 3123, 4000, 4018, 4023, 4123, 5000, 5024, 5500, 5700, 6000, 6500, CE2200, Décor Excel 5018, Décor Excel Pro 5124, Jem Gold, MC4000, MC3000, MC6600, MC3500, MC4018, MC5700, MC7000, MC7500, MC8000, MC9000, MC9700, MC10000, MC10001, MC11000, My Excel 4023, Schoolmate S-3015

Elna 6003, 6004, 8006, 8007, 9006, CE20

**077.822.661**



**Ref : 260502009**

Needle clamp with screw

Babylock BL1750

Elna 149, 200, 220, 225, 230,

240, 250, 255, 2551

Husqvarna 140, 160

White 1418, 2335

**077.260.502**



**Ref : 385029**

Needle clamp with screw

Singer Quantum DSX,

Quantum LE

Elna EL9010

**077.385.029**



**Ref : 387467**


Needle clamp

Elna EL9010

Singer Quantum XL5000

**077.387.467**

## DRŽAĆI IGALA - PINCES AIGUILLES - HUSQVARNA - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 4117503-02</b> Needle clamp stopper for 4117502-01 <b>078.411.750</b></p>	 <p><b>Ref : 4127738-01 = 4125818-01, 4117502-01</b> Husqvarna 90, 95, 100, 105, 120, 150, 180, 185, 190, 210, 230, 250, 310, 315, 320, 325, 330, 335, 350, 400, 415, 425, 435, 500, 530, 535, 540, 545, 550, 555, 600, 610, 620, 630, 770, 775, 940, 945, 950, 960, 980, 990, 1050, 1070, 1090, 1100, 1140, 1200, 1250, 630, Designer 1, Designer 2, Designer SE, #1, #1+, Sophia <b>077.412.773</b></p>
 <p><b>Ref : 260502009</b> Needle clamp with screw Babylock BL1750 Elna 149, 200, 220, 225, 230, 240, 250, 255, 255I Husqvarna 140, 160 White 1418, 2335 <b>077.260.502</b></p>	<p><b>Ref : X75205-001</b> Bernina 800 Brother 730DE-760DE-900D-929D-934D-920D-PL1050-640D-925D-935D-929D-1034D Husqvarna 900-560ED <b>077.075.205</b></p>







## DRŽAĆI IGALA - PINCES AIGUILLES - JANOME - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 624185002</b> Janome Combi DX, Combi 10, 203, 303 <b>077.624.185</b></p>	 <p><b>Ref : 785004020 = 98-785004-02/000</b> Janome 204D-234D-334-334D-434D-534D-1110DX-3434D Pfaff 752-4752 <b>077.785.004</b></p>
 <p><b>Ref : 801506008 = 102047008 = 395711-35 = X54859051 = 129627001</b> Needle clamp &amp; screw Babylock BL1550 - BL1556 Brother VX808 - VX809 Elna 1010-2002-2004-2006-2100-2300-3003FS-3005-3007 Janome 105-106-108-3125-352-353-370-372-373-470-533-556-562-591-592-605-620-625FA-640-641-642-Jem Gold 660-663-669-670-671-672-674-676-692-792-844-900-910-920-980-990-1004-1506-1508-1518-1612-1622-1803-1804-1814-1818-1822-5001-JA1500-RE3000-S650-S750-SR2000-SR2100-TB12 Kenmore 385.15616500 Pfaff 204-205-206-207-208-209-210-211-521-541-721-741 <b>077.801.506</b></p>	
 <p><b>Ref : 822661007</b> Needle clamp Janome 659, 2014, 2015, 2018, 2022, 2030, 2122, 2200, 3000, 3015, 3023, 3123, 4000, 4018, 4023, 4123, 5000, 5024, 5500, 5700, 6000, 6500, CE2200, Décor Excel 5018, Décor Excel Pro 5124, Jem Gold, MC4000, MC3000, MC6600, MC3500, MC4018, MC5700, MC7000, MC7500, MC8000, MC9000, MC9700, MC10000, MC10001, MC11000, My Excel 4023, Schoolmate S-3015 Elna 6003, 6004, 8006, 8007, 9006, CE20 <b>077.822.661</b></p>	
 <p><b>Ref : SNZ3</b> Babylock BL3000, BL4000, BL5000 Brother 190, 5050, XL5032 Janome 370, 470 Riccari 414, 500, 515, 525, 555FA, RM570, RE571, RE581, RE591, 606, 665u, 666FA, 706, 707, 805, 807, 808E, 888, 906E, 2600, 2910, 2925, 2950, 2800, 3300, 3400, 2900, 3500, 3600, 4001, 4003, 7500, 8400, 8500, 9150, 9160, 9600, 9700, 9800, 9900 <b>077.300.761</b></p>	

## DRŽAĆI IGALA - PINCES AIGUILLES - KENMORE - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 801506008 = 102047008 = 395711-35 = X54859051 = 129627001</b> Needle clamp &amp; screw Babylock BL1550 - BL1556 Brother VX808 - VX809 Elna 1010-2002-2004-2006-2100-2300-3003FS-3005-3007 Janome 105-106-108-3125-352-353-370-372-373-470-533-556-562-591-592-605-620-625FA-640-641-642-Jem Gold 660-663-669-670-671-672-674-676-692-792-844-900-910-920-980-990-1004-1506-1508-1518-1612-1622-1803-1804-1814-1818-1822-5001-JA1500-RE3000-S650-S750-SR2000-SR2100-TB12 Kenmore 385.15616500 Pfaff 204-205-206-207-208-209-210-211-521-541-721-741 <b>077.801.506</b></p>	
 <p><b>Ref : KM43268 = DPX43268 = 28782</b> (use SKL or SKL1 screw) Babylock BL5500 Kenmore 158.19142 <b>077.043.268</b></p>	 <p><b>Ref : SNZ11</b> Babylock BL1400 Riccari 469FA <b>077.300.763</b></p>

## DRŽAĆI IGALA - PINCES AIGUILLES - PFAFF - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 993-70-774</b> Needle bar &amp; clamp Pfaff 774-784-786-787-788</p> <p><b>077.993.774</b></p>	 <p><b>Ref : 93-034127-15</b> Needle clamp body Pfaff 800, 875, 905, 955, 1006, 1007, 1010, 1037, 1047, 1051, 1067, 1069, 1071, 1147, 1151, 1171, 1213, 1214, 1216, 1217, 1371, 1400, 1467, 1469, 1471, 1472, 1473, 1475, 2010, 2012, 2014, 2020, 2024, 2025, 2027, 2030, 2034, 2040, 2056, 2124, 2140, 2144, 2170, 4240, 4250, 4260, 4860, 4870, 6085, 6091, 6112, 6122, 6152, 6230, 6232, 6250, 6270, 7510, 7530, 7550, 7560, 7570</p> <p><b>077.034.127</b></p>	
 <p><b>Ref : 93-034128-05</b> Needle clamp GIB Pfaff, fits most models</p> <p><b>077.034.128</b></p>	 <p><b>Ref : 93-034130-15</b> Needle holder Pfaff, C-clip, fits most models</p> <p><b>077.034.130</b></p>	 <p><b>Ref : 93-040784-91</b> Needle clamp Pfaff 230-260-262-332-1196-1197-1199-1209-1222-1222E-1229 Naumann 8014-26</p> <p><b>077.040.784</b></p>
 <p><b>Ref : 541788</b> Needle clamp Pfaff 9020U53 Singer 20U</p> <p><b>085.541.788</b></p>		
 <p><b>Ref : 801506008 = 102047008 = 395711-35 = X54859051 = 129627001</b> Needle clamp &amp; screw Babylock BL1550 - BL1556 Brother VX808 - VX809 Elna 1010-2002-2004-2006-2100-2300-3003FS-3005-3007 Janome 105-106-108-3125-352-353-370-372-373-470-533-556-562-591-592-605-620-625FA-640-641-642-Jem Gold 660-663-669-670-671-672-674-676-692-792-844-900-910-920-980-990-1004-1506-1508-1518-1612-1622-1803-1804-1814-1818-1822-5001-JA1500-RE3000-S650-S750-SR2000-SR2100-TB12 Kenmore 385.15616500 Pfaff 204-205-206-207-208-209-210-211-521-541-721-741</p> <p><b>077.801.506</b></p>		

## DRŽAĆI IGALA - PINCES AIGUILLES - WHITE - NEEDLE CLAMPS - NADELKLAMMERN

 <p><b>Ref : 12093</b> White 299D, 8234, S34, S34D</p> <p><b>077.012.093</b></p>	 <p><b>Ref : 141000364</b> White 1500, 1600</p> <p><b>078.141.000</b></p>	 <p><b>Ref : 163822</b> Needle clamp gib Singer 600, 603, 604, 620, 620E, 625, 626, 628, 629, 630, 630E, 635, 636, 638, 639, 640E, 645, 646, 649, 714, 717 School, 719, 724, 734, 737, 750, 755, 756, 758, 770, 774, 775, 776, 778, 2001, 2001A</p> <p><b>077.163.822</b></p>
 <p><b>Ref : 1643124-00</b> Necchi 533, 535</p> <p><b>077.164.312</b></p>		 <p><b>Ref : 11934</b> White 7234-7934DW-SL34-SL34D</p> <p><b>077.011.934</b></p>
 <p><b>Ref : 6368</b> White 1523</p> <p><b>077.006.368</b></p>		

## DRŽAČI IGALA - PINCES AIGUILLES - SINGER - NEEDLE CLAMPS - NADELKLAMMERN



**Ref : 072270**  
Needle clamp  
Singer 14J334  
White 2000

**077.072.270**

**Ref : 072777**  
Needle bar  
Singer 14J334

**077.072.777**



**Ref : 168507**  
Needle clamp  
Babylock BL66, BL67  
(Audrey)  
Singer 117, 2623

**077.168.507**



**Ref : 129853001** - Needle clamp with screw  
Babylock BL1556, BL2160, BL7500, BL8000, BL8500, BL6200, BL2100, BL6000, BL2150, BL6700, BL7000  
Brother 320, 461, 761, 845, XL4010, XL4020, XL4030, XL4030, XL4050, XL4060, 7029, XL4040, PS1000, PS1200, PS1250, PS1700, PS1750, PS1800, PS1950, PS2100, VX1010, VX1020, VX520, VX540, VX560, VX620, VX640, VX660, VX707, VX710, VX760, VX780, VX800, VX807, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XL711, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200  
Janome Schoolmate S-3015  
Singer 3001, 3002, 3003, 3004, 3005, 3011, 3012, 3013, 3014, 4001, 4002, 4005, 4006, 4009, 4011, 4012, 4015, 4016, 4019, 4022, 5502, 5504, 5505, 5508, 5522, 5524, 5525, 5528


**077.129.853**



**Ref : 163123 = 172224 = 540382**  
Needle clamp w/ screw

Singer 401, 403, 404, 417, 500, 503, 600, 603, 604, 620, 620E, 625, 626, 628, 629, 630, 630E, 635, 636, 638, 639, 640E, 645, 646, 648, 649, 714, 717 School, 719, 724, 734, 737, 750, 755, 756, 758, 770, 774, 775, 776, 778, 900-3, 920, 920-3, 925, 1000G, 1030, 1036, 1040G, 1060, 1200, 1411, 1425N, 1425U, 2000, 2001, 2005, 2010, 6704, 6705

**077.163.123**



**Ref : 163822**  
Needle clamp gib  
Singer 600-603-604-620-620E-625-626-628-629-630-630E-635-636-638-639-640E-645-646-649-714-717 School-719-724-734-737-750-755-756-758-770-774-775-776-778-2001-2001A

**077.163.822**



**Ref : 2050**  
Needle bar  
Singer 15-30

**077.002.050**



**Ref : 2054** Needle clamp, Universal  
Brother 360, 451, 661, 681, 741, 751, 1681, XL781, XL791, XL851, XL1351, XL1561, XL1781  
Janome 125, 366, 443, 444, 445, 446, 447, 495, 507, 508, 509, 510, 532, 534, 535, 543, 545, 548, 551, 575, 586, 589  
Necchi 537, 2216, 2416, 2716, BU Nova  
Riccar 608, REC5900, SZ702  
Singer 27, 127, 128, 15CL, 185 (185J), 15-30, 15-86, 15-96, 15-97, 15-87, 66-6, 99-13

**077.002.054**



**Ref : 283059**  
GIB Needle clamp  
Singer Quantum CXL,  
Quantum XL1, LE, XL100

**077.283.059**



**Ref : 283060**  
Needle clamp w/ screw  
Singer Quantum CXL,  
DSX II, XL1, XL10, XL50

**077.283.060**



**Ref : 313552**  
GIB Needle clamp  
Singer 4610-4613-4617-4623-6233-6234-6235-9410

**077.313.552**



**Ref : 313798**  
Needle clamp w/ screw  
Singer 4552, 4572, 4610, 4613, 4617, 4622, 4623, 4663, 5910, 5932, 6233, 6234, 6235, 6267, 6268, 6408, 6412, 6423, 9005, 9008, 9010, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9034, 9044, 9110, 9113, 9117, 9124, 9130, 9133, 9137, 9143, 9210, 9217, 9224, 9240, 9323, 9334, 9410, 9420, 9936, 4562, 6416

**077.313.798**



**Ref : 319729** Needle clamp w/ screw  
Singer 240-247AP-247-249-258-288-290C-353-354-360-362-366-367-1247-1263-1280-1288-2210-2404-3101-3102-3103-3105-6102-6104-6105-6106-6110-6112-6114-6115-6116-6120-6130-6136-6146-6152-6156-6174-6184-7101-7102-7104-7105-7106-7108-7110-7136-7174-8100-8200-8500-8600-8774-9500-9600-9802-9836

**077.319.729**



**Ref : 353631** Needle clamp  
Singer 1802, 1803, 1812, 1852, 1853, 1862, 1872, 1873, 2302, 2303, 2304, 2315, 2330, 2430, 2502, 2503, 2504, 2515, 2530, 3314, 3317, 3343, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4825, 4828, 4830, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6210, 2440

**077.353.631**



**Ref : 357430 = 35729-900, 357429, 357429-001**  
Needle clamp w/ screw  
Singer 507, 2440, 2502, 2503, 2504, 2505, 2515, 2517, 2530, 2543, 2722, 2724, 2730, 2732, 2950, 3270, 3314, 3317, 3343, 4205, 4206, 4210, 4212, 4220, 4228, 4620, 5017, 5028, 5040, 5050, 5050C, 5417, 5430, 5605, 5610, 5705, 5710, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 57817, 57820, 57825, 6038, 6305, 6310, 6314, 6318, 6620, 7211, 7212, 8220, DX14, FM17, FM19, FM22, HD102, HD105, HD110

**077.357.430**



**Ref : 37943-803** GIB Needle bar  
Singer 2302, 2303, 2304, 2315, 2330, 2440, 2502, 2503, 2504, 2505, 2515, 2517, 2530, 2543, 2950, 3270, 3314, 3317, 3343, 6102, 6104, 6105, 6106, 6110, 6112, 6114, 6115, 6116, 6120, 6122, 6124, 6125, 6126, 6130, 6136, 6146, 6152, 6156, 6174, 6184

**077.037.943**



**Ref : 385029**  
Needle clamp w/ screw  
Singer Quantum DSX,  
Quantum LE  
Elna EL9010

**077.385.029**



**Ref : 386106**  
Needle clamp  
Singer Quantum XL100

**077.386.106**



**Ref : 387017**  
Needle clamp  
Singer Quantum XL150,  
Quantum XL1000

**077.387.017**



**Ref : 387467**  
Needle clamp  
Elna EL9010  
Singer Quantum XL5000

**077.387.467**



**Ref : 388194**  
Needle clamp  
Singer Quantum XL6000

**077.388.194**



**Ref : 45285**  
Needle clamp  
Singer 201-201/2-221-222-223-301-1200/1-15/88-15/90-15/91-15/125

**077.045.285**



**Ref : 541788**  
Needle clamp  
Pfaff 9020U53  
Singer 20U

**085.541.788**

## DRŽAČI IGALA - PINCES AIGUILLES - SINGER - NEEDLE CLAMPS - NADELKLAMMERN



**Ref : 543623=155459**  
Needle clamp w/ screw  
Singer 327, 328, 329, 337, 338, 347,  
348, 413K, 416K, 418, 457, 466, 476,  
477, 478, 502, 507, 509, 510, 513,  
514, 518, 522, 527, 530, 533, 534,  
538, 543, 560, 814, 833, 935U, 1022,  
6513, 6522, 6528, 6533, 6543, 6544,  
6548  
**077.543.623**



**Ref : 550398**  
Needle clamp  
Singer 14U555

**077.550.398**



**Ref : 550590**  
Needle clamp  
Singer 14U544, 14U554

**077.550.590**



**Ref : 550797**  
Needle clamp  
Singer 14U557

**077.550.797**




**Ref : 74815**  
Needle clamp  
Singer 132Q, 1500, 2638

**077.074.815**



**Ref : 86822-803**  
GIB Needle clamp  
Singer 237, 239

**077.086.822**



**Ref : G10245000**  
Needle clamp w/ screw  
Singer 1105-1106-1116-  
1120-1130-1507-1525-  
1748-8280-8770  
**077.102.450**



**Ref : H10205000**  
Needle clamp  
Singer 3709-3722-3810-  
3820-3825-6510-6550-  
7312-7322-7350-7350/1-  
7360-7380  
**077.102.050**



**Ref : HP31961**  
Needle clamp  
Singer XL3400

**077.031.961**



**Ref : HP32098-2**  
Needle clamp  
Singer 9910-9920-9940

**077.032.098**



**Ref : SNZ1 = 36353 = SNZ6** Needle clamp with screw  
Babylock BL500, BL1000, BL1050, BL1400, BL2000, BL2200, BL2800  
Kenmore 158.10401, 158.12312, 158.13400, 158.14510, 158.17530, 158.13402  
Necchi 538, 539, 3204FB  
Riccar 469FA, 900, 925, 1900, 1925, 800R, R1500, R1570, R1570FB, R1800, R1850, R250, R7620, RE640  
Singer 5102, 5107, 5122, 5123, 5124, 5127  
White 202, 208, 219, 310, 423, 447, 505, 510, 639, 644, 645, 646, 690, 710, 734, 793, 954, 967, 1418, 1760,  
4040, 4075  
**077.300.760**



**Ref : 87154**  
Needle clamp w/ screw  
Singer 2009-7256-7430-  
7436-7463-7467-7469-  
7469Q-7470-8763 Curvy-  
8780 Curvy  
**077.087.154**