

DRŽAĆI KALEMA - **BABYLOCK** - SPOOL PINS - GARNROLLENSTIFTE/GARNROLLENHALTER



Ref : X57045001 Felt spool
Brother PC5000-PC6000-
PC7000-PC7500-PC8000-
PC8895-PE100-PE150-PE180D-
PE200
Babylock BL9500-ESI-ESI2-EMI1
-EM2-Espree
Bernina Deco 500, Deco 600
077.057.045



Ref : 822020503 = 395719-39, 98-822020-50/300, 395713-81, 822020307 Spool cap large
Babylock BL20A (Anna), BL30A (Molly)
Elna 444-664-740 (Excellence)-2600-3003-3005-3007-3230-5000-6000-7000-8000-9000-Club-Diva
Janome 634, 3434D, 4119, 4618LE, 6018, 8077, 660 (Jem Gold), 661 (Jem Gold 2), 2000-9000, JP760 -
Jem Platinum 760, 720, 521, 734D, 1110DX, DC3018, DC3050, MC3000, MC7700QCP (Horizon), MS3015
Kenmore 158.13570, 385.162213, 385.1652400, 385.18630890
Necchi 3610, 6150
Pfaff 752, 4752
077.822.020



Ref : 130012053 = 130012024, 130012054, 130012003, 130012001, 130012-004, 130012-054, 130012-053
Spool cap large
Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BL6600, BL7500, BL8000, BL8500, BL9500, BLN (Esante),
ESN (Encore), ESI, ESI2, EMI1, ESE, ESE2, ESG Ellageo, ESL, ESP (Espire), BL6200, BL2100, BL6000, BL2150, BL6700, BLCC
(Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLQC, BLG (Ellegante), BLG 2 (Ellegante 2),
BLMY (Melody), BLTP (Tempo), EM2 (Espree), EMP6, INT (Intrigue)
Bernina Deco 500, Deco 600
Brother 845, CS8060, CS8100, CS8150, CS8200, HE-240, NV4000D, NX200, NX400, NX600, PC2800, PC3000, PC5000, PC6000,
PC6500, PC7000, PC7500, PC8000, PC8895, PE100, PE150, PE180D, PE200, PC8200, PC8500, PR-600, PS1000, PS1250,
PS1700, PS1750, PS1800, PS1900, PS1950, PS2100, PS2200, PS2300, PS2500, SE-350, ULT2001, ULT2002, XL3010, XL3022,
XL3025, XL3027, XL3030, XL3100, XL3200, XL4010, XL4020, XL4030, XL4040, XL4050, XL4060, XL6040, XL6050, XL6060,
XL6452, XL6552, XL6562, XR16, XR31, XR33, XR34, XR35, XR37, XR40, XR46, XR52C, XR65T
077.130.012



Ref : 986013-032 = 986013046, 986013032
Spool cap large
Babylock BL66, BL67
(Audrey)
Singer 117, 2623, 4166
White 1740, 2037
077.986.013



Ref : X55260152 = XE1372001, X55260052, X55260153, X55260002, X55260053
Spool pin medium
Babylock BL40, BL40A (Grace), BL200A (Elizabeth), BL9500, BLCC (Crafter's
Choice), BLCC2 (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2
(Decorator's Choice), BLQC, BLG (Ellegante), BLG 2 (Ellegante 2), BLMY
(Melody), BLN (Esante), BLSO (Ellisimo), BLTP (Tempo), ESN, ESI, ESI2, EM1,
EM2, EAC, SE1, SE2, ESN (Encore), ESL, ESE, ESE2, ESG, ESP (Espire), INT
Bernina Deco 500, Deco 600
Brother CE-5500, CE-5500PRW, CP-6500, CP-7500, CS-8060, CS-8100, CS-
8150, CS-8200, DS-120, DS-140, FS-20, FS-40, FS-40WT, HE-240, HS-2500,
NV-4000D, NX-200, NX-400, NX-600, PC-2800, PC-3000, PC-5000, PC-6000,
PC-6500, PC-7000, PC-7500, PC-8000, PC-8895, PE-100, PE-150, PE-180D,
PE-200, PC-8200, PC-8500, ULT-2001, ULT-2002, XR-4040
077.055.260


Ref : 205-0201-10A-X05 = 205-0201-10A
Spool cap
Babylock BL101, BL34-60, BL80, BL90, BLSE200, BLSE300, BL3-
318, BL3-407, BL3-408, BL415, BL3-416, BL3-417, BL3-418, BL3-
426, BL4-428, BL4-428D, BL428K, BL4-428NS, BL4-436, BL4-
436DF, BL3-437, BL6-437D, BL4-605, EA605, BL4-625, BL4-714,
BL4-728, BL4-728D, BL4-736, BL4-736D, BL4-738, BL4-738D, BL4-
738NS, BL4-838D, BL3200, BL5180, BL518NS, BL5260, BL5260D,
BL5280E, BL5280ED, BL5360ED, BL5380ED, EA605
077.205.020



Ref : 130013043 = 130013003, 130013154, 130013124, 130013053 & 130013-154
Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BL2100, BL2150, BL6000, BL6150, BL6200, BL6600,
BL6700, BL7500, BL7800, BL8000, BL8500, BL9500, ESL, ESP (Espire), EM1, EM2, ESN (Encore), ESI, ESI2, EMI1, ESE, ESE2,
ESG Ellageo, ESG2, ESG3, BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY
(Melody), BLQC, BLTP (Tempo), BLG (Ellegante), EM2, INT (Intrigue)
Bernina Deco 500, Deco 600
Brother 845, CS8060, CS8100, CS8150, CS8200, HE-240, NV4000D, NX200, NX400, NX600, PC2800, PC3000, PC5000, PC6000,
PC6500, PC7000, PC7500, PC8000, PC8895, PE100, PE150, PE180D, PE200, PC8200, PC8500, PS1000, PS1250, PS1700,
PS1750, PS1800, PS1900, PS1950, PS2100, PS2200, PS2300, PS2500, SE-350, ULT2001, ULT2002, XL2021, XL3010, XL3022,
XL3025, XL3027, XL3030, XL3100, XL3200, XL4010, XL4020, XL4030, XL4040, XL4050, XL4060, XL6040, XL6050, XL6060,
XL6452, XL6552, XL6562, XR31, XR33, XR34, XR35, XR37, XR40, XR46, XR52C, XR65T
Riccicar R3100, R3200
077.130.013



Ref : B8202-S01A-33
Spool cap
Babylock BLE1, BLE8
077.820.211



Ref : 986014-033 = 986014033, 986014003
Spool cap small
Babylock BL66, BL67
(Audrey)
Singer 117, 2623
White 1740, 2037
077.986.014



Ref : 822019509 = 395719-38
Spool cap small
Babylock BL20A (Anna),
BL30A (Molly)
Elna 2600-3003-3005-3007-
3230-5000-6000-7000-8000-
9000-Club-Diva
Janome 660 (Gem Gold),
661 (Jem Gold 2), 2000-
9000, 4119, 4618LE, 8077,
DC3018, DC3050, JP760,
MC4800, MS3015
Kenmore 158.13570,
385.162213, 385.1652400
Necchi 6150
077.822.019



Ref : 142603001 = XA2111050, XA2111-000, XA2111000
Babylock BL500A (Jane),
BLQP (Quilter's Choice Pro)
Brother PQ-1300, PQ-1500,
PQ-1500S
077.142.603

Ref : 60682
Spool cap
Babylock BL302, BL450
077.060.682

















Ref : R1A2223210
Spool cap
Singer Quantum L-500
Babylock BLQ2
077.222.321



Ref : XA0679050
Spool cone holder
Brother PQ1300-PQ1500-
PQ1500S-PR600-PC600C-
PR600/II-PR600/2-PR620-PR650
Babylock BL500A (Jane), BLQP
(Quilter's Choice Pro)
077.000.679

Ref : 60596
Spool holder
Babylock BL302
077.060.596

DRŽA I KALEMA - BABYLOCK - SPOOL PINS - GARNROLLENSTIFTE/GARNROLLENHALTER

	<p>Ref : 615-0102-02A = 200-0102-02A, 408-0102-02A Spool holder Babylock BL80, BL90, BL4-428, BL5180, BLE8, BLCS, BLE8W, BLE1AT, BLSE200 077.615.102</p>	<p>Ref : 006R1A0039 Spool holder Babylock BLQ2 Singer Quantum L-500 077.100.039</p>	 <p>Ref : XC4654051 Spool pin (B) Babylock BL200A (Elizabeth), BLCC (Crafter's Choice), BLCC-2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY (Melody), BLQC, BLR2, BLTP (Tempo) Brother NX200, NX400, NX600 077.046.540</p>
	<p>Ref : XA3336051 Spool pin extra Babylock ESE-ESE2-ESG-ESN (Encore)-ESL-ESP (Espire) Brother CS8072-PE300S-PE400D-PC8200-PC8500-ULT2001-ULT2002 077.003.336</p>	 <p>Ref : XC3834021 Spool pin (extra) Brother CS8060-CS8100-CS8150-NV500D-SE270D Babylock INT (Intrigue) 077.383.402</p>	 <p>Ref : XE2241001 Spool pin vertical Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2) Brother HE-240 077.022.410</p>
	<p>Ref : 625031500 = 395719-42 Spool pin (vertical) Babylock BL20A (Anna), BL30A (Molly) Elna 2600, 3230 Janome 4119, 4618LE, 5024, 5124, 8077, DC3018, DC3050, MC3500, MC4800, MC4800QC, MC8000, MC9000, JP760 Kenmore 158.13570, 385.162213, 385.18230, 385.1652400 Necchi 6150 077.625.031</p>	 <p>Ref : X52190051 Spool pin shaft Babylock BL2100-BL6000-BL6700 Brother PS1700-PS1900-PS1950-PS2100-PS2200-PS2300-PS2500 077.052.190</p>	
	 <p>Ref : XA4471051 Spool pin shaft Babylock BL1556-BL2160 Brother XL3010-XL3022-XL3025-XL3027-XL3030-XL3100-XL3200-XL4010-XL4020-XL4030-XL4050-XL4060-XL4040-XR31-XR33-XR34-XR35-XR37-XR40 077.044.710</p>	 <p>Ref : XA0628021 = XA0628121 Spool pin spring Babylock B15, B17, B21 Brother CE5000PRW, CS-770, LS1217, LS1520, LS2125, LS2720, LS2725, LS2820, LS2825, LS2920, LX-3125, RS15, RS25, RS35, VX1120, VX1125, VX1140, XL5010, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XL5011, XL5012, XL5020, XL5030, XL5060, XL5070, XL5100, XL5130, PX100, PX150, PX200, PX300, XL5021, XL5022, XL5031, XL5032, XL5050 077.062.802</p>	
	<p>Ref : X58708001 Spool pin Babylock EMI1, EM2 Bernina Deco 500, Deco 600 Brother PE100-PE150-PE180D-PE200 Simplicity SEI 077.058.708</p>	 <p>Ref : X53629051 Spool pin Brother PS1750-XL2010-XL2015-XL2021-XL2022-XL2025-XL2027-XL2030-XR29-XR23 Babylock BL2150-BL6150-BL6600 077.536.290</p>	<p>Ref : XC5949051 Spool pin Babylock EMP6 Brother PR600 077.594.905</p>
	<p>Ref : 659067005 = 395753-18 Spool pin Babylock BL30A Elna 2600 Janome DC3018, DC3050 Necchi 6150 077.659.067</p>	 <p>Ref : X59053051 = X59053052 Spool pin Babylock BL1556, BL2160, BL6200, BL6300, BL6700, BL6800, ESL, ESN (Encore), ESP (Espire) Brother CS8072, PC2800, PC3000, PC6500, PS1000, PS1250, PS1800, PS1950, PS2100, PS2200, PS2300, PS2500, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XL4010, XL4020, XL4030, XL4040, XL4050, XL4060, XL6040, XL6050, XL6060, XL6452, XL6552, XL6562, XR31, XR33, XR34, XR35, XR37, XR40, XR46, XR52C, XR65T 077.059.053</p>	
	<p>Ref : 652302004 = 395710-32 Spool pin Babylock BL18, BL18A (Natalie), BL1170 Elna 2002, 2004, 2006 Kenmore 385.12912, 385.12712, 385.12714, 385.12618, 385.12612, 385.11607, 385.11608, 385.11682, 385.12014, 385.12049, 385.12102, 385.12216, 385.12314, 385.12318, 385.12514, 385.12545, 385.12581 Janome 1004, 1506, 1508, 1518, 1612, 1622, 1814, 1818, 1822 077.652.302</p>	 <p>Ref : XA1786051 = XA1786053 Spool pin Babylock BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BLMY (Melody), BLN (Esante), BLTP (Tempo), ESE, ESE2, ESG, BLN Esante, BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLQC, BLSO (Ellisimo), BLG (Ellegante), BLG2 (Ellegante 2) Brother HE-240, NV1500D, NV4000D, NX200, NX400, NX600, PC8200, PC8500, SE-350, ULT2001, ULT2002, ULT2003D 077.017.860</p>	
	<p>Ref : 130920021 = 130920051, 130920001 Spool pin Babylock B15, B17, B21, BL60, BL200, BL702, BL713, BL722, BL1500, BL1550, BL2400, BL6150, BL6200, BL6300, BL6600, BL6700, BL6800, BL9500, EM1, EM2, ESI, ESE2, ESE3, ESPREE Brother 7029, BM2600, BM3500, CE-4000, CE-5000PRW, CS100T, CS4000, CS6000, CS6000T, EX-660, HS-1000, L25, L35, LS-590, LS1217, LS1520, LS1717, LS2125, LS2720, LS2725, LS2820, LS2825, LS2920, PS1200, PS2250, PS2360, PS2470, PS3100, PX100, PX150, PX200, PX300, RS15, RS25, RS35, XL2120, XL2121, XL2130, XL2140, XL2150, XL2220, XL2230, XL2240, XL2250, XL2600, XL2610, XL2620, XL3500, XL3500T, XL3510, XL3520, XL3800, VX707, VX710, VX760, VX780, VX800, VX807, VX808, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, VX1010, VX1020, VX1100, VX1120, VX1125, VX1140, VX1200, VX1435, XL2500, XL3200, XL5010, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XR33, XR34, XR-6600, XR7700 Riccari R3100, R3200 Simplicity SE3, SL6600, SL8020, SL8130, SL8220, SL9130, SL9150, SL9240 Singer 3001, 3002, 3003, 3004, 3005, 3011, 3012, 3013, 3015, 4001, 4002, 4005, 4006, 4009, 4011, 4012, 4015, 4016, 4019, 4022 077.130.920</p>		