








**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - BABYLOCK - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : X53553101</b> Position bracket Babylock BL7500-BL8500- BL9500-ESI-ES2 Brother 845-PC5000-PC6000 -PC7000-PC7500-PC8000- PC8895 <b>077.535.531</b></p>	 <p><b>Ref : X54134001</b> Position bracket Babylock BL2100-BL2150- BL6000-BL6200-BL6600- BL6700 Brother PS1000-PS1250- PS1700-PS1750-PS1800- PS1900-PS1950-PS2100 <b>077.541.340</b></p>	 <p><b>Ref : X59803001</b> Position bracket Babylock EMI1-EM2- ESPREE Bernina Deco 500-Deco 600 Brother PE100-PE150- PE180D-PE200 <b>077.598.030</b></p>
 <p><b>Ref : XA1976101</b> Position bracket Babylock ESE-ESE2 Brother PC3000-PC8200- PS2200-PS2300-PS2500 <b>077.197.610</b></p>	 <p><b>Ref : XA5869001</b> Position bracket Babylock ESN-ESL-ESP- ESG-ESG2-ESG3 Brother PC858500- ULT2001-ULT2002 <b>077.586.900</b></p>	 <p><b>Ref : XC2555021=XC2555121</b> Bobbin case bracket Babylock BLCC-BLDC-BLQC- INT Brother CS8060-CS8150- CS8200-NX200-NX400-NX600 -NV500D-SE270D <b>077.255.502</b></p>
 <p><b>Ref : XC8406151 = XC8406251</b> Position bracket Babylock BLG (Ellegante)- BLG 2 (Ellegante) Brother NV1000-NV2500D- NV4000D <b>077.840.615</b></p>	 <p><b>Ref : X56025101</b> Hook presser inner Babylock BL9500-ESI-ESI2- EMI1 Bernina Deco 500 Brother PC5000-PC6000- PC7000-PC7500-PC8000- PE100-PS1900-PS8895 <b>077.560.251</b></p>	

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - BERNINA - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : 316.020.131</b> Spring shuttle Bernina 830-1530 oscillating <b>077.316.020</b></p>	 <p><b>Ref : 317.006.33</b> Tension spring Bernina 830-1530 <b>077.317.006</b></p>	 <p><b>Ref : X59803001</b> Position bracket Babylock EMI1-EM2- ESPREE Bernina Deco 500-Deco 600 Brother PE100-PE150- PE180D-PE200 <b>077.598.030</b></p>
 <p><b>Ref : X56025101</b> Hook presser inner Babylock BL9500-ESI-ESI2- EMI1 Bernina Deco 500 Brother PC5000-PC6000- PC7000-PC7500-PC8000- PE100-PS1900-PS8895 <b>077.560.251</b></p>		

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - BROTHER - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : X53553101</b> Position bracket Babylock BL7500-BL8500- BL9500-ESI-ES2 Brother 845-PC5000-PC6000 -PC7000-PC7500-PC8000- PC8895 <b>077.535.531</b></p>	 <p><b>Ref : X54134001</b> Position bracket Babylock BL2100-BL2150- BL6000-BL6200-BL6600- BL6700 Brother PS1000-PS1250- PS1700-PS1750-PS1800- PS1900-PS1950-PS2100 <b>077.541.340</b></p>	 <p><b>Ref : X56025101</b> Hook presser inner Babylock BL9500-ESI-ESI2- EMI1 Bernina Deco 500 Brother PC5000-PC6000- PC7000-PC7500-PC8000- PE100-PS1900-PS8895 <b>077.560.251</b></p>
 <p><b>Ref : X59803001</b> Position bracket Babylock EMI1-EM2- ESPREE Bernina Deco 500-Deco 600 Brother PE100-PE150- PE180D-PE200 <b>077.598.030</b></p>	 <p><b>Ref : XA1976101</b> Position bracket Babylock ESE-ESE2 Brother PC3000-PC8200- PS2200-PS2300-PS2500 <b>077.197.610</b></p>	 <p><b>Ref : XA5869001</b> Position bracket Babylock ESN-ESL-ESP- ESG-ESG2-ESG3 Brother PC858500- ULT2001-ULT2002 <b>077.586.900</b></p>
 <p><b>Ref : XA8116051</b> Hook bracket Brother XL6040-XL6050- XL6060-XL6452-XL6562- PS2250-PS2360-PS2470- PS3100-XR46-XR52C- XR65T <b>077.811.605</b></p>	 <p><b>Ref : XC2555021=XC2555121</b> Bobbin case bracket Babylock BLCC-BLDC-BLQC- INT Brother CS8060-CS8150- CS8200-NX200-NX400-NX600- NV500D-SE270D <b>077.255.502</b></p>	 <p><b>Ref : XC4939021 = XE1863001</b> Position bracket Brother CE4000-CS100- CS100T-CS4000-CS6000- CS6000i <b>077.493.902</b></p>
 <p><b>Ref : XC8406151 = XC8406251</b> Position bracket Babylock BLG (Ellegante)-BLG 2 (Ellegante) Brother NV1000-NV2500D- NV4000D <b>077.840.615</b></p>		

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - ELNA - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**



**Ref : 401170-10**  
 Spring for bobbin case  
 Elna Lotus 14-22-24-32-34-35-36-52  
 Elna Star 11-13-21-23-31-33-41-43-62-64-72-74  
**077.401.170**



**Ref : 401220-10**  
 Bobbin case base  
 Elna Air Electronic 38, Air Electronic 39, Air Electronic 58, Air Electronic 59, Air Electronic 68, Air Electronic 69, Lotus 14, Lotus 22, Lotus 24, Lotus 32, Lotus 34, Lotus 35, Lotus 36, Lotus 52, Star 11, Star 13, Star 21, Star 23, Star 31, Star 33, Star 41, Star 43, Star 62, Star 64, Star 72 & Star 74  
**077.401.220**



**Ref : 411570-02**  
 Bobbin extractor  
 Elna most models  
**077.411.570**

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - HUSQVARNA - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**




**Ref : 4114596-01**  
 Spring bobbin case  
**077.411.459**



**Ref : 4120968-01**  
 Latch bobbin case  
 Husqvarna #1 - # 1 Plus - 1100-620-630-630NS-1050-1070-1090  
**077.412.096**



**Ref : 4120974-01**  
 Tension spring bobbin case  
 Husqvarna #1 - 1100 New Style  
**077.412.099**



**Ref : 4121633-01**  
 Spring latch bobbin case  
 Husqvarna #1 - # 1 Plus - 1100  
**077.412.633**



**Ref : 4123655-01**  
 Stopper bobbin case  
 Husqvarna 210-230-250-310-320-330-315-325-335-350-400-500-1140-S205-S500  
**077.412.365**



**Ref : 4124716-01**  
 Tension spring  
 Husqvarna 530-540-550-600  
**077.412.471**



**Ref : 4124773-01**  
 Stopper bracket bobbin case  
 Husqvarna 210-215-225-230-234-250-300-310-315-320-325-330-335-340-340D-341-341D-350-400-415-425-430-431-435-435C-440-441-444-500-530-540-550-600-605-Iris-Rose-Sarah  
**077.412.473**



**Ref : 4311045-01**  
 Finger bobbin case  
 Husqvarna 2780-2781  
**077.431.106**



**Ref : 4119668-02**  
 Screw bobbin case stop  
 Husqvarna S210-S250-S300-S310-S325-S335-S341-S350-S400-S415-S500-S205-S225  
**077.411.966**

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - PFAFF - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**



**Ref : 9026**  
 Tension spring for 9076  
 Pfaff 1196-1197-1211-1212-1213-1214-1216-1217-1222-1229-130-230-260-262-280-290-332-360-362-800-875  
**074.400.340**



**Ref : 91-001382-15** Screw tension  
 Pfaff 1019-1047-1051-1067-1069-1071-1147-1151-1171-1371-1467-1469-1471-1472-1473-1475-2010-2020-2030-2034-2040-6085-6091-6112-6122-6152-6230-6250-6270-7510-7530-7550-7560-7570-905-1006-1007-1037-6232-1010-2140-955  
**077.001.382**



**Ref : 91-105500-91**  
 Latch for bobbin case 91-105544-91  
 Pfaff 1472-1475-7510-7570  
**077.105.500**



**Ref : 93-035314-91** Position bracket  
 Pfaff 875-900-905-955-1006-1007-1010-1020-1025-1027-1030-1035-1037-1040-1047-1051-1067-1069-1071-1151-1171-1371-1400-1469-1471-1472-1473-1475-1500-2010-2030-2040-6000-7000-7500-7510-7530-7550-7560-7570-471-472-473-475  
**077.035.314**



**Ref : 93-040314-91** Position bracket  
 Pfaff 1100-1197-1211-1212-1213-1214-1216-1217-1222-1229  
**077.040.314**



**Ref : 98-695545-01** Stopper  
 Pfaff 280-290-70-80-90  
**077.695.545**



















**Ref : 93-035087-15** Position bracket spring  
**077.035.087**



**Ref : NBL 806=907** Stopper  
 Pfaff  
**074.400.810**

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - SINGER - PIECES POUR BOITES A CANETTES  
BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : 105035</b> Bobbin case tension spring Singer 206K, 306W <b>077.105.035</b></p>	 <p><b>Ref : 125288</b> Bobbin case latch for 125291 Singer 15-88, 15-90, 15-91, 15-125 <b>077.125.288</b></p>	 <p><b>Ref : 125293</b> Tension spring for 125291 Singer 15-88, 15-90, 15-91, 15-125 <b>085.125.293</b></p>
 <p><b>Ref : 15098</b> Bobbin case spring Singer 15-30, 31-15 <b>077.015.098</b></p>	 <p><b>Ref : 15141</b> Bobbin case latch for JO1313W Singer HA1 <b>070.710.050</b></p>	 <p><b>Ref : 15278</b> Bobbin case tension spring Singer 16U, 118 Consew 18 <b>074.400.400</b></p>
 <p><b>Ref : 153022</b> Position finger Singer 290-290C-737-750-755-756-758-770-775-778-1000G-1040G-1060-1411-1425N-1425U <b>077.153.022</b></p>	 <p><b>Ref : 155464</b> Washer position bracket Singer 413-416K-417-418-466-476-477-478 <b>077.155.464</b></p>	 <p><b>Ref : 155468</b> Position bracket Singer 1247-1263-240-247AP-250 Srs-288-347-348-360-362-366-367-413K-416K-417-418-457-476-477-478-466-714-717-717 School-719-734 <b>077.155.468</b></p>
 <p><b>Ref : 163058</b> Position finger bracket Singer 600-603-604-620-625-626-628-629-630-630E-635-636-638-639-640E-645-646-648-649-700-714-717 School-719-724-734-737-750-755-756-758-770-774-775-776-778-1060-1040G-1411U-1425U <b>077.163.058</b></p>	 <p><b>Ref : 163300</b> (incl. spring-screw-nut) Repair kit bobbin case Singer 290C-600-603-604-620-620E31-625-626-628-629-630-630E-635-636-638-639-640E-645-646-648-649-700-714-717 School-719-724-734-737-750-755-756-758-770-774-775-776-778-1060-1040G-1411U-1425U <b>077.163.300</b></p>	 <p><b>Ref : 163320</b> Position bracket Singer 600-603-604-620-620E31-625-626-628-629-630-630E-635-635E3-635E6-635E7-636-638-639-640E-645-646-649 <b>077.163.320</b></p>
 <p><b>Ref : 172086</b> Position bracket Singer 401-403-404-500-503 <b>077.172.086</b></p>	 <p><b>Ref : 172202</b> Tension spring Singer 240-252-257-258-259-347-360-362-366-367-401-403-404-413K-416K-417-418-457-466-476-477-478-500-501-503-714-717 School <b>077.172.202</b></p>	 <p><b>Ref : 172987</b> Retaining bracket Singer 737-750-755-756-758-770-775-778 <b>077.172.987</b></p>
 <p><b>Ref : 174237</b> Thread pull off Singer 1411N-1425U-600-700-750 <b>077.174.237</b></p>	 <p><b>Ref : 206731</b> Latch pin Alphasew 221 Singer 221-301 <b>077.206.731</b></p>	 <p><b>Ref : 206736</b> Bobbin case latch Alphasew 221 Singer 221-301 <b>077.206.736</b></p>
 <p><b>Ref : 210736</b> Bobbin case latch spring Alphasew 221 Singer 221-301 <b>074.400.520</b></p>	 <p><b>Ref : 283194</b> Position bracket Singer Quantum CXL-Quantum XL1-Quantum XL10-Quantum XL50 <b>077.283.194</b></p>	 <p><b>Ref : 2975</b> Bobbin case latch spring Singer 15CL <b>074.400.220</b></p>
<p><b>Ref : 310883</b> Bobbin case tension spring for 421326 bobbin case Singer 247AP-288-353-354-502-507-509-510-513-514-518-522-527-530-533-534-538-560-714-717 School-719-724-734-774-776-800-827-830-834-844-935U-1022-1247-1263-1280-1288-1482-1485-1486-1488-1490-1492-1802-1803-1812-1852-1853-1862-1872-1873-2102-2105-2106-2108-2110-2112-2114-2118-2210-2302-2303-2304-2315-2330-2404-2430-2440-2502-2503-2504-2515-2517-2530-2732-2950-3100-3101-3102-3103-3105-3130-3140-3314-3317-3343-4325-4522-4525-4526-4528-4530-4538-4552-4562-4572-4610-4620-4622-4825-4828-4830-5017-5028-5040-5050-417-5430-5605-5610-5705-5710-5802-5805-5806-5808-5810-5812-5814-5816-5817-5818-5820-5825-5830-5838-5910-5932-6011-6012-6021-6038-6100-6102-6104-6105-6106-6110-6120-6130-6136-6146-6152-6156-6174-6184-6201-6202-6211-6212-6214-6215-6217-6221-6233-6500-6513-6522-6528-6533-6543-6544-6548-6606-6620-7004-7015-7021-7025-7028-7033-7101-7102-7104-7105-7106-7108-7110-7136-7174-7211-7212-8002-8007-8019-8100-8200-8220-8500-8600-8734-8774-9005-9008-9010-9015-9018-9020-9022-9027-9030-9032-9034-9044-9110-9130-9134-9210-9323-9334-9408-9410-9416-9420-9423-9430-9432-9444-9500-9502-9505-9518-9600-9602-9605-9606-9608-9610-9612-9614-9618-9802-9836-9936-413K13-57815-57815C-57817-57820-57825-93220-CG500-CG550-CG590-DL17-DX14C-FM17-FM19-FM22-HD110-Dressmaker 300 - Necchi 538 <b>077.310.883</b></p>		
 <p><b>Ref : 310884</b> Bobbin case tension spring for 421326 bobbin case Singer Apollo <b>077.310.884</b></p>	 <p><b>Ref : 312738</b> Position bracket Singer 4610-4613-4617-4623-4663-6234-6235-6250-6251-6267-6268-7000-7005-7037-7043-7050-7060-9113-9117-9124-9133-9137-9143-9217-9224-9240-9900 <b>077.312.738</b></p>	 <p><b>Ref : 313067-900</b> Position bracket spring Singer 4610-5910-6233-9110-9130-9210-9410-9420-9423-9432 <b>077.313.067</b></p>
 <p><b>Ref : 313089</b> Position bracket Singer 4552-4562-4572-4610-4622-5910-5932-6233-7004-7028-7033-8002-8007-8019-9005-9008-9010-9015-9018-9020-9022-9027-9030-9032-9034-9044-9110-9130-9134-9210-9323-9334-9408-9410-9416-9420-9423-9430-9432-9444-93220 <b>077.313.089</b></p>	 <p><b>Ref : 313395-900</b> Retaining plate Singer 5910-9030-9034-9130-9033 <b>077.313.395</b></p>	 <p><b>Ref : 32567</b> Tension spring Singer 185 <b>077.032.567</b></p>

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - SINGER - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**



**Ref : 353511**

Bobbin case retaining plate

Singer 611, 1280, 1288, 1802, 1803, 1812, 1852, 1853, 1862, 1872, 1873, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 2502, 2503, 2504, 2515, 2530, 3101, 3102, 3103, 3105, 3314, 3317, 3343, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4620, 4825, 4828, 4830, 5017, 5028, 5040, 5050, 5605, 5610, 5705, 5710, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 6021, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6221, 6606, 6620, 7015, 7021, 7025, 8100, 8200, 8220, 8500, 8600, 8774, 9500, 9502, 9505, 9518, 9600, 9602, 9606, 9608, 9610, 9612, 9614, 9618, 9605, 9936, 57817, 57820, 57825, 9802-9836, DL17, DX-14C, FM17, FM19, FM22

**077.353.511**



**Ref : 358021**

Retaining plate

Singer 2950-6038-CG500-CG550-CG590-2722-2724-2730-2732-2950-6038-HD102-HD105-HD110

**077.358.021**



**Ref : 382437**

Position bracket

Singer 737-750-755-756-758-770-775-778-1000G

**077.382.437**



**Ref : 383910**

Retaining plate

Singer 2010

**077.383.910**



**Ref : 383912**

Position bracket

Singer 2010-2210

**077.383.912**



**Ref : 386219**

Bobbin case stopper

Singer Quantum XL100

**077.386.219**



**Ref : 40393**

Bobbin case latch

Singer 206K-206W-306K-306W-319

**070.710.060**



**Ref : 40394**

Bobbin case tension spring for bobbin case part 52237

Brother B714-B735-DDL227-DDL555-DDL5530-DL5550

Consew CN2230R-99-103-104-210-220-230

Janome 701-710-761-765

Singer 95-96CL-188K1-191-195-241-241/11-241/12-241/13-251-281-281/1-281/3-281/21-291U-

331K-366K-491-591-600W-660A-660W-701/710-761/765-1300-1400W

Tacsew T405-T810

White 666-1164

**074.400.440**



**Ref : 422129-930**

Retaining plate

Singer 221 Featherweight-

6102-6104-6105-6106-6110-

6120-6130-6136-6146-6152-

6156-6184-7102-7104-7105-

7106-7110-7136-7211-7212

**077.422.129**



**Ref : 44873-451 = 44873 = 44873-001** Position bracket

Singer 353, 354, 500, 502, 507, 509, 510, 513, 514, 518, 522, 527, 530, 533, 534, 538, 543, 560, 611, 714, 719, 724, 734, 774, 776, 800, 834, 844, 1022, 1280, 1288, 1482, 1485, 1486, 1488, 1490, 1492, 1802, 1803, 1812, 1852, 1853, 1862, 1872, 1873, 2102, 2105, 2106, 2108, 2110, 2112, 2114, 2118, 2210, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 2502, 2503, 2504, 2505, 2515, 2517, 2530, 2543, 2950, 3101, 3102, 3103, 3105, 3270, 3314, 3317, 3343, 4205, 4206, 4210, 4212, 4220, 4228, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4620, 4825, 4828, 4830, 5017, 5028, 5040, 5050, 5605, 5610, 5705, 5710, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 6011, 6012, 6021, 6038, 6102, 6104, 6105, 6106, 6110, 6120, 6130, 6136, 6146, 6152, 6156, 6174, 6184, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6221, 6522, 6528, 6533, 6543, 6544, 6548, 6606, 6620, 7015, 7021, 7025, 7101, 7102, 7104, 7105, 7106, 7108, 7110, 7136, 7174, 7211, 7212, 8100, 8200, 8220, 8500, 8600, 8774, 9500, 9502, 9505, 9518, 9600, 9602, 9605, 9606, 9608, 9610, 9612, 9614, 9618, 9936, 57817, 57820, 57825, 413K13, 6513, 717 School, 935U, 9802-9836, CG500, CG550, CG590, CM17, DL17, DX-14C, FM17, FM19, FM22, HD102, HD110 & SM14 **077.044.873**



**Ref : 45789**

Bobbin case tension spring

Alphasew 221

Singer 221-301

**077.045.789**



**Ref : 51058 = 50994**

Bobbin case stopper

Singer 2662-7422-7424-

7426-7442-7444-7446

**077.050.994**



**Ref : 730150**

Bobbin case stop plate

Singer 117-2623

**077.730.150**



**Ref : 730152**

Bobbin case stopper

Singer 117-2623

**077.730.152**



**Ref : 76118**

Position finger

Singer 1500-2662-2638

**077.076.118**



**Ref : 81025**

Bobbin case stop plate

Singer 118

**077.081.025**



**Ref : 81026**

Bobbin case stop spring

Singer 118

**077.081.026**



**Ref : 81027**

Position finger

Singer 118

**077.081.027**



**Ref : 86239**

Position finger

Singer CE100-CE200-

CE250

**077.086.239**



**Ref : HP32849**

Position bracket

Singer 9910-9920-9940

**077.032.849**



**Ref : NBL211 = NBL406**

Bobbin case spring for

283195, 283603

Singer Quantum CXL-

Quantum XL1-Quantum

XL10-Quantuml XL50

**074.400.820**



**Ref : 141345-819**

Position bracket screw

Singer 413-416K-417-

418-457-458-466-476-

477-478

**077.141.345**



**Ref : 200964**

Bobbin case latch screw

Singer 221 Featherweight,

301

**077.200.964**



**Ref : 354229-451**

Screw position bracket

Singer 714-717 School-

719-724-734-774-776-

800

**077.354.229**






**Ref : 490468**

Star disc





For all bobbin cases

**070.710.020**

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - SINGER - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : 1380</b> Bobbin case tension mounting screw Singer 206K-306W-306</p> <p><b>074.300.320</b></p>	 <p><b>Ref : 592</b> Bobbin case latch screw Singer 140Q-1105-1116-1120-1130-1732-3001-3002-3003-3004-3005-3011-3012-3013-3014-4001-4002-4006-4009-4011-4012-4015-4016-4019-4022</p> <p><b>074.300.260</b></p>	 <p><b>Ref : 591</b> Bobbin case tension screw Singer 15/30-31/15-140Q-227-228-237-238-1105-1107-1116-1120-1130-1507-1525-1732-1748-2050-2250-2259-2263-2273-2300-3001-3002-3003-3004-3005-3011-3012-3013-3014-3015-3208-3116-4001-4002-4005-4006-4009-4011-4012-4015-4016-4019-4022-4166-5101-5102-5107-5122-5123-5124-5127-5522-5528-8280-8770-30215-30518</p> <p><b>074.300.250</b></p>
<p><b>Ref : 421871</b> Retaining ring for 421864-451 Singer 4218</p> <p><b>077.421.871</b></p>	<p><b>Ref : 445808</b> Bobbin case retaining plate stud washer Singer 1802, 1803, 2302, 2303, 2304, 2315, 2330, 2440, 2502, 2503, 2504, 2515, 2530, 3314, 3317, 3343, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4620, 4825, 4828, 48230, 5017, 5028, 5040, 5050, 5605, 5610, 5705, 5710, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 9500, 9502, 9505, 9518, 9600, 9602, 9605, 9606, 9608, 9610, 9612, 9614, 9618, 57817, 57820, 57825, DX-14C, FM17, FM19 &amp; FM22</p> <p><b>077.445.808</b></p>	
<p><b>Ref : 446417</b> Retaining plate clip Singer 5040</p> <p><b>077.446.417</b></p>	<p><b>Ref : 514674-451</b> Retaining ring nut Singer 4522-4622-7028-9005-9008-9010-9410</p> <p><b>077.514.674</b></p>	 <p><b>Ref : 181554</b> Position finger plate Singer 900-900/3-920/3</p> <p><b>077.181.554</b></p>
 <p><b>Ref : 44892</b> Bobbin case retaining plate stud spring FM22, FM19, FM17, DX-14C, 9936, 9836, 9802, 9618, 9614, 9612, 9610, 9608, 9606, 9605, 9602, 9600, 9518, 9505, 9500, 5838, 5830, 5825, 5820, 5818, 5817, 5816, 5814, 5812, 5810, 5808, 5806, 5805, 5802, 57825, 57820, 57817, 5710, 5705, 5610, 5605, 5050, 5040, 5028, 5017, 4830, 4828, 4825, 4620, 4538, 4530, 4526, 4525, 4522, 3317, 3314, 2530, 2515, 2504, 2503, 2502, 2440, 2330, 2315, 2304, 2303, 2302, 1803 &amp; 1802</p> <p><b>077.044.892</b></p>	 <p><b>Ref :</b> <b>XC8406151=XC8406251</b> Position bracket Babylock BLG (Ellegante) - BLG2 (Ellegante 2) Brother NV1000-NV2500D-NV4000D</p> <p><b>077.840.615</b></p>	
 <p><b>Ref : XC4939021 = XE1863001</b> Position bracket Brother CS100T-CS4000-CS6000</p> <p><b>077.493.902</b></p>	 <p><b>Ref : 312607</b> Retaining plate spring Singer 4552-4622-7028-9005-9008-9010-9410</p> <p><b>077.312.607</b></p>	 <p><b>Ref : 511477</b> Position bracket Singer 702-722-740-744-746-784-786</p> <p><b>077.511.477</b></p>
 <p><b>Ref : NBL101=NBL396</b> Bobbin case spring For JO1313Z, no back For Husqvarna-Brother-Janome-Singer-Babylock</p> <p><b>074.400.830</b></p>	 <p><b>Ref : NBL522</b> Bobbin case spring For 52237NBL, no back Singer 95-96</p> <p><b>074.400.800</b></p>	

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - JANOME - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : 627567001</b> Stopper Janome 2014-2015-MC3000-DC3018-MC3500-MC4023-661 (Jem Gold 2)</p> <p><b>077.627.567</b></p>	 <p><b>Ref : 822011109</b> Stopper Janome 6000</p> <p><b>077.822.011</b></p>	 <p><b>Ref : 822530006</b> Position bracket Janome 6000</p> <p><b>077.822.530</b></p>
 <p><b>Ref : 825516005</b> Stopper Janome MC8000</p> <p><b>077.825.516</b></p>		

**DRŽAČI KUČIŠTA - ONDERDELEN SPOELHULZEN - WHITE - PIECES POUR BOITES A CANETTES**  
**BOBBIN CASE PARTS - ERSATZTEILE FÜR SPULENKAPSEL**

 <p><b>Ref : 7091</b> Stop finger hook White 510-690-710-711-712-713-714</p> <p><b>077.007.091</b></p>	 <p><b>Ref : 837</b> Bobbin case spring White Rotary</p> <p><b>077.000.837</b></p>	
--	---	--