



HVATAČI KONCA - DRAADHEVELS - TENDEUR DE FIL - TAKE UP - FADENHEBEL

| | | |
|--|--|--|
|  <p>Ref : 129561001 Take up Brother 320-461-761- VX520-VX540-VX560- VX707-VX710-XL711 077.129.561</p> |  <p>Ref : 137730051 Take up Babylock BL7500-BL8000- BL8500 Brother 845 077.137.730</p> |  <p>Ref : X52396051 Take up Brother PS1200 077.052.396</p> |
|  <p>Ref : X52620051 Take up Brother XL2010-XL2015- XL2021-XL2022-XL2025- XL2030-XR29-XR23 077.052.620</p> |  <p>Ref : X52651151 Take up lever Babylock BL1556-BL2150-BL2160- BL6200 Brother XL4010-XL4020-XL4030- XL4050-XL4060-XL4040-PS1000- PS1250-PS1750-PS1800-XL3010- XL3022-XL3025-XL3027-XL3030- XL3100-XL3200-XR31-XR33-XR34- XR35-XR37-XR40-VX1100-VX1200 077.052.651</p> |  <p>Ref : X53511051 Take up lever Brother 7029, VX1010, VX1020, VX760, VX780, VX800, VX807, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980 Singer 5502, 5504, 5505, 5508, 5522, 5524, 5525, 5528 077.053.511</p> |
|  <p>Ref : X56047051 Take up link Babylock ESI, ESI2 Brother PC7000-PC7500- PC8000-PC8895 077.056.047</p> |  <p>Ref : X56048051 Take up Babylock ESI, ESI2 Brother PC7000-PC7500- PC8000-PC8895 077.056.048</p> |  <p>Ref : X58776151 Take up Babylock EMI1, EM2, Espree Bernina Deco 500, Deco 600 Brother PE100-PE150- PE180D-PE200 077.058.776</p> |
|  <p>Ref : XA0716151 Take up lever Babylock BL500A (Jane) Brother PQ1300 077.007.161</p> |  <p>Ref : XA1112151 = XA1112121 Take up lever Babylock B15, B17, B21 Brother LS1217, LS1520, LS2125, LS2720, LS2725, LS2820, LS2825, LS2920, LX-3125, PX100, PX150, PX200, PX300, RS15, RS25, RS35, VX1120, VX1125, VX1140, XL5010, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700 077.011.121</p> | |
|  <p>Ref : XA1862051 Take up lever Babylock ESE, ESE2, ESN (Encore), ESP (Espire) Brother PC2800-PC3000- PC6500-PC8200-PC8500 077.018.620</p> |  <p>Ref : XA2505021 Take up Babylock BL6300-BL6800 Brother PS2200, PS2300, PS2500, XL6040, XL6050, XL6060, XL6452, XL6552, XR46, XR52C, XR65T 077.025.050</p> |  <p>Ref : XA6110001 Take up Brother PE300S, PE400D 077.061.100</p> |
|  <p>Ref : XA9010051 Take up Brother PQ1500 077.090.100</p> |  <p>Ref : XA9441051 Thread take up Babylock ESG, ESG2, ESG3 Brother ULT2001, ULT2002D, ULT2003D 077.094.410</p> |  <p>Ref : XC2442051 = XC2442151, XC2442154, XC2442153 Babylock BL200A (Elizabeth), BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLTP (Tempo) Brother NV1000, NX200, NX400 077.024.420</p> |
|  <p>Ref : XC3833051 = XC3833151 Take up lever Babylock INT (Intrigue) Brother CS8100-CS8200- CS8060-CS8150-NV500D- SE270D 077.038.330</p> |  <p>Ref : XC6239051 Take up Brother NV2500D, NX600 077.062.390</p> |  <p>Ref : XZ0394051 Take up Brother NV4000D 077.003.940</p> |
|  <p>Ref : XC8564031 Take up lever Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2) Brother CE-4000, CE-5000PRW, CE -5500, CE-5500PRW, CP-6500, CP- 7500, CS-100, CS-4000, CS-6000, DS-120, DS-140, FS-20, FS-40, FS- 40WT, HS-2500, SE-350, XR-4040 077.085.640</p> |  <p>Ref : 625506006 = 395711-32, 625506109 Take up lever Babylock BL18A (Natalie) Elna 1000 (Sew Fun), 2002, 2004, 2006 Janome 1004-1508-1518-1612-1622- 1803-1804-1806-1810-1812-1814- 1816-1818-1822-TB-12 077.625.506</p> |  <p>Ref : 822512002 Take up Janome 2015-2022-2030 077.822.512</p> |
|  <p>Ref : 825538003 Take up Janome MC7000, MC7500 077.825.538</p> |  <p>Ref : 830517002 Take up Janome MC8000 077.830.517</p> |  <p>Ref : 834015007 Threader holding plate Janome 5000 077.834.015</p> |
|  <p>Ref : 137145 Take up Singer 6408-6412-6416- 6423 077.137.145</p> |  <p>Ref : 168503 Take up Singer 117 077.168.503</p> |  <p>Ref : 170204 Take up Singer 5102-5107-5123- 5127 077.170.204</p> |

HVATAČI KONCA - DRAADHEVELS - TENDEUR DE FIL - TAKE UP - FADENHEBEL

| | | |
|---|--|--|
|  <p>Ref : 283206 Take up Singer Quantum CXL-XL1- XL10-XL50 077.283.206</p> |  <p>Ref : 313182 Take up assembly Singer 4613-4617-4623- 6267-6268-9900 077.313.182</p> |  <p>Ref : 314694 Take up Singer 4552-4562-4572-4610- 4622-5910-5932-7028-7033- 9005-9008-9010-9015-9018- 9022-9027-9032-9044-9110- 9130-9134-9210-9323-9334- 9408-9410-9416-9420-9423- 9430-9432-9444-93220 077.314.694</p> |
|  <p>Ref : 87134 Take up lever Singer 7256-7422-7424- 7426-7436-7442-7444-7446- -7462-7463-7464-7466- 7467-7468-7469-7469Q 077.087.134</p> |  <p>Ref : 314695-001 Head end module Singer 4552-4662-7028- 9005-9008-9010 077.314.695</p> |  <p>Ref : 314699 Take up Singer 4613-4617-4623- 4663-6250-6251-7000-7005- 7037-7043-7050-7060-9113- 9117-9124-9217-9224-9240 077.314.699</p> |
|  <p>Ref : 385057 Take up Singer DSX, DSX II, Quantum LE 077.385.057</p> |  <p>Ref : 386247 Thread take up Singer Quantum XL100, Quantum XL150, Quantum XL1000 077.386.247</p> |  <p>Ref : 422311 Take up assembly Singer 714-717 School-6102- 6104-6105-6106-6110-6120-60- 66-61466152-6156-6174-6184- 7100-7101-7102-7104-7105- 7106-7108-7110-7114-7136- 7171-7174-7180 077.422.311</p> |
|  <p>Ref : 445664 Thread take-up lever assembly Singer 3101-241-247-249- 547 077.445.664</p> |  <p>Ref : 445672 Take up assembly Singer 263, 288, 563, 588, 1802, 1803, 1812, 1852, 1862, 1872, 1873, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 2502, 2503, 2504, 2515, 2530, 2950, 3101, 3102, 3103, 3105, 3314, 3317, 3343, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4620, 4825, 4828, 4830, 5017, 5028, 5040, 5050, 5605, 5610, 5705, 5710, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 6011, 6012, 6021, 6038, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6221, 6606, 6620, 7025, 9802-9836, 57817, 57820, 57825, FM17, FM19, FM22 077.445.672</p> |  <p>Ref : 76182 Take up Juki HZL-35Z Singer 2623-2662-2638 077.076.182</p> |
|  <p>Ref : 75088 Take up Singer 1500 077.075.088</p> |  <p>Ref : E1A2513001 Take up Singer 1105-1106-1116- 1120-1130 077.251.300</p> |  <p>Ref : 304.269.040 Take up Bernina 540, 640, 700- 750, 801-850 077.304.269</p> |
|  <p>Ref : 387608 Take up Singer Quantum XL5000, Quantum XL6000 077.387.608</p> |  <p>Ref : 411220-20 Take up Elna Star 62, Star 64, Star 72 077.411.220</p> |  <p>Ref : 93-042132-91 Take up lever Pfaff 1209-1211-1212-1213- -1214-1215-1216-1217- 1221-1222-1222E-1229- 1245 077.042.132</p> |
|  <p>Ref : HA-1-56 Take up Singer Alphasew HA1 077.010.156</p> |  <p>Ref : 1250002-441 Take up Toyota 6300, 6600 White 7234 077.002.441</p> |  <p>Ref : 4113404-01 Take up lever Husqvarna 6260, 6360, 6430 077.411.340</p> |
|  <p>Ref : 93-036132-91 Take up Pfaff 875, 1047, 1051, 1067, 1069, 1071, 1147, 1151, 1171, 1371, 1467, 1469, 1471, 1472, 1473, 1475, 2010, 2020, 2040, 6112, 6122, 6152, 6230, 6250, 6270, 7510, 7530, 7550, 7560, 7570, 1010, 905, 1006, 1007, 1037, 6232, 1010 077.036.132</p> |  <p>Ref : 17281 Take up White 1560 077.017.281</p> |  <p>Ref : 17281 Take up White 1560 077.017.281</p> |