
















OJNICE IGLENJAČE - BIELLE BARRE AIGUILLE - CRANK SLIDES - NADELSTANGENGELLENK

 <p>Ref : 137720051 Crank slide Brother 845 Babylock BL7500- BL8000-BL8500 077.137.720</p>	 <p>Ref : X56824151 Needle bar crank Brother PC5000-PC6500 Babylock BL9500 077.568.241</p>	 <p>Ref : X57745051 Crank slide Brother PC5000-PC6500 Babylock BL9500 077.577.450</p>
 <p>Ref : X55944051 Crank needle bar Babylock ESI-ESI2 Brother PC7000-PC7500- PC8000-PC8895 077.559.440</p>	 <p>Ref : X55991051 Crank slide Babylock ESE-ESE2-ESL- ESI-ESI2-ESP (Espire) Brother PC7000-PC7500- PC8000-PC8895 077.559.910</p>	 <p>Ref : X56822051 Crank slide Babylock BL6700 Brother PS1900-PS1950 -PS2100 077.568.220</p>
 <p>Ref : X52751050 Crank slide Brother XL2010-XL2015- XL2021-XL2022-XL2025- XL2030-XR29-XR23 077.527.510</p>	 <p>Ref : 93-036266-41 Crank roller Pfaff 1171-1400 series 077.036.266</p>	 <p>Ref : 137528-901 Crank slide Singer 4552-4572-4622- 5910-6408-6412-6416-6423- 7028-9005-9008-9010-9015- 9018-9027-9032-9134- 93220 077.137.528</p>
 <p>Ref : 352753 Crank slide Singer 2210-4522-4528- 4530-8734-8834 077.352.753</p>	 <p>Ref : 382776 Crank slide Singer 2000-2005 077.382.776</p>	 <p>Ref : 383267 Crank slide Singer 2001-2001A-2010 <i>Flange protrudes on 1 side</i> 077.383.267</p>
 <p>Ref : 383286 Crank slide Singer 900-900/3-920- 920/3-925-2001-2001a <i>Flange protrudes on both side</i> 077.383.286</p>	 <p>Ref : 4114948-01 Crank slide Husqvarna 3610-5610-5710- 6030-6170-6230-6240-6260- 6270-6360-6370-6430-6440- 6460-6470-6570-6690 077.411.494</p>	 <p>Ref : 445224 Crank slide Singer 241-247-249-263- 288-547-563-588-2404- 3101-3102-3103-3105 077.445.224</p>
 <p>Ref : 446357 = 359783-901 Thread take up link Singer 4205-4206-4210- 4212-4220-4228-4528 077.446.357</p>	 <p>Ref : 5611 Rod needle bar crank White ESP4000 077.005.611</p>	 <p>Ref : 75060 Crank slide Singer 132Q-2638-2662- 7422-7424-7426-7463-7467- 7469-7469Q-7470-CE100- CE150-CE200-CE250- CE350-SES1000 078.075.060</p>
 <p>Ref : HA-1-20 Crank slide Alphasew HA1 077.000.120</p>	 <p>Ref : KS-1 Hand crank Alphasew HA1 077.300.490</p>	 <p>Ref : 313533 Crank slide Singer 4613-4617-4623- 9410 077.313.533</p>
 <p>Ref : XA1289121 = XA1289151 Needle bar crank rod assembly Brother LS-2125i 077.001.289</p>	 <p>Ref : 80073 Needle bar crank set Singer 7422 077.080.073</p>	<p>Ref : X52650151 Needle bar crank rod assembly Babylock BL6150-BL6300- BL6800-BL7800-ESN (Encore) Riccar R3100 077.526.501</p>