

OVERLOCKTONGEN - DOIGT MAILLEUR - CHAINING TONGUE - OVERLOCK ZUNGE

| | | |
|---|--|--|
|  <p>Ref : 330530 Chaining tongue Pfaff 794, 796</p> <p>077.330.530</p> |  <p>Ref : A1136-334-0A0 Tongue Juki 634D, 654D</p> <p>077.113.633</p> |  <p>Ref : 127858001 Chaining tongue Brother 526-526D-546-546D-626D-634D-730DE-760DE-834DP Husqvarna 535-560-800-900-535D</p> <p>077.127.858</p> |
|  <p>Ref : XB0309-001 Stitch tongue Brother 929D, 1034D</p> <p>077.020.309</p> |  <p>Ref : 396002-37 Chaining tongue Elna L4</p> <p>077.396.037</p> |  <p>Ref : 396002-54 Chaining tongue Elna L5</p> <p>077.396.054</p> |
|  <p>Ref : 787611000 Stitch tongue Janome 434D, 534D</p> <p>077.787.611</p> |  <p>Ref : 412792 Chaining tongue Singer 14U13A, 14U53A</p> <p>077.412.792</p> |  <p>Ref : 550450 = 93-415504-50/000 Chaining tongue Pfaff 14U544, 14U554, 14U555, 14SH654, 14SH644, 14CG754, 14CG744</p> <p>077.550.450</p> |
|  <p>Ref : 556043 = 93-415560-43/000 Chaining tongue Pfaff 4772 Singer 14U557</p> <p>077.556.043</p> |  <p>Ref : B10321000 Tongue moving Singer 14T948DS</p> <p>077.103.210</p> |  <p>Ref : 406-8102-01B Chaining tongue foot Babylock BL3200, BL3-318, BL3-406, BL3-407, BL3-408, BL3-416, BL3-417, BL3-418, BL3-426, BL3-437, BL3-437D, BL4-428, BL4-428 NS, BL4-738, BL4-738D, BL4-738 (NS), BL4-838D, BL5180, BL5180 (NS), BL5280E, BL5280ED, BL5280E (NS), BL5380ED</p> <p>078.406.810</p> |
|  <p>Ref : 408-5102-01A Chaining tongue Babylock BL3200, BL3-408, BL3-418</p> <p>078.408.510 Screw = SI-30010 Washer = WS-03101 Nut = NI-30001</p> |  <p>Ref : 4TW-5102-01A Chaining tongue Babylock BL3-428, BL4-428, BL4-738, BL5180, BL5280E</p> <p>077.010.036 Screw = SI-30010 Washer = WS-03101 Nut = NI-30001</p> |  <p>Ref : B4721-02A-OY Chaining tongue Babylock BL1, BLE1DX, BLE1LX, BLE1SX</p> <p>077.472.102</p> |
|  <p>Ref : B4721-04A-PY = B4721-03A-PY Chaining tongue (adjusting) Babylock BLE8 (Evolvve), BLE1AT, BLE8W-2 (Evolution)</p> <p>077.472.104</p> |  <p>Ref : HA-G12-01A Chaining tongue Babylock BL4-428NS, BL4-728, BL4-738 (NS), BL5180 (NS), BL5280E (NS)</p> <p>077.010.037</p> |  <p>Ref : SE-G12-01A Chaining tongue (stitch finger) Babylock BL5260, BL5260D, BL4-428D, BL4-728D, BL4-738D, BL5280ED, BL5360D, BL5360ED, BL5380ED, BL4-838D, BL80, BL90, BLSE200, BLSE300, BL415 & BL428K</p> <p>077.010.038</p> |
|  <p>Ref : X77090-001 Looper holder chaining tongue Brother 925D, 935D</p> <p>077.077.090</p> |  <p>Ref : X77091-000 Stitch tongue holder Brother 640D, 920D, 925D, 934D, 935D, PL1050</p> <p>077.077.091</p> |  <p>Ref : XB0401-001 Stitch tongue holder Brother 929D, 1034D</p> <p>077.020.401</p> |
|  <p>Ref : SI-30010 = 4TW-5102-01A, 408-5102-01A Chaining tongue screw Babylock BL3200, BL5180, BL5280E, BL3-408, BL3-418, BL4-428, BL4-738</p> <p>077.030.010</p> |  <p>Ref : NI-30001 Chaining tongue nut Babylock BL3200, BL3-408, BL3-418, BL4-428, BL4-738, BL5180, BL5280E</p> <p>077.030.001</p> |  <p>Ref : WS-03101 Chaining tongue washer Babylock BL3-408, BL3-418, BL4-428, BL4-738, BL3200, BL5180, BL5280E</p> <p>077.003.101</p> |
|  <p>Ref : X77094-001 Chaining tongue Brother 934D, 920D, PL1050, 640D, 925D, 935D</p> <p>077.077.094</p> |  <p>Ref : 396002-14 Chaining tongue Elna L1 series, 10000 & up</p> <p>078.396.002</p> |  <p>Ref : SS-06001 Chaining tongue screw Babylock BL4-605</p> <p>077.060.010</p> |
|  <p>Ref : X141542-001 Chaining tongue screw Bernina 800 Brother 730DE, 760DE Husqvarna S900, 560ED</p> <p>077.141.542</p> |  <p>Ref : 047200842 Spring pin tongue holder Brother 640D, 920D, 925D, 934D, 935D, PL1050</p> <p>077.472.008</p> |  <p>Ref : B3721-02A-OY Needle plate finger Babylock BLE1, BLE1DX, BLE1AT (Imagine) Screw = SM-4020351-S</p> <p>077.372.102</p> |