





























PODIZAČI STOPICE - LEVIER PIED DE BICHE - PRESSER BAR LIFTER - HEBEL

 <p>Ref : 125165003 Presser foot lifter Brother VX520, VX540, VX560, VX620, VX640, VX660, VX710, VX757, VX760 077.125.165</p>	 <p>Ref : 137738051 Presser foot lifter Babylock BL7500, BL8000, BL8500 077.137.738</p>	 <p>Ref : 138655001 Presser bar lifter Brother 7029, PS1200, VX780, VX800, VX807, VX808, VX809, VX810, VX880, VX890, VX920, VX940, VX950, VX970, VX980, VX1010, VX1020 077.138.655</p>
 <p>Ref : 138877-005 Presser foot lifter Brother 526-526D-546-546D-626D-634D-834DP Husqvarna 535D 077.138.877</p>	 <p>Ref : 138877-006 Presser foot lifter Brother 640D-920D-934D-PL1050 077.138.878</p>	 <p>Ref : 141000520 Presser foot lifter White 1599 077.141.520</p>
 <p>Ref : 141000756 Presser foot lifter White 970, 979 077.141.756</p>	 <p>Ref : 163583 Presser bar lifter Singer 337-338-401-405-413K-416K-418-457-477-478-500-503-635E-648 077.163.583</p>	 <p>Ref : 170296 Presser bar lifter Singer 5102, 5107 077.170.296</p>
 <p>Ref : 172989 Presser bar lifter Singer 714-717-719-724-734-737-750-755-756-758-770-774-775-776-778 077.172.989</p>	 <p>Ref : 173796 Presser bar lifter Singer 237, 239 077.173.976</p>	 <p>Ref : 206-8202-00A Presser bar lifter Babylock BL5380ED, BL80, BL90, BL5260, BL4-428, BL4-625, BL4-714, BL4-728, BL4-728D, BL4-736, BL4-736D, BL4-738D, BL4-838D, BLSE200 077.206.820</p>
 <p>Ref : 2141002366651 Presser bar lifter Husqvarna 905, 910, 936 078.214.100</p>	 <p>Ref : 29-924993-70165 Presser bar lifter Pfaff 794, 795, 796 077.993.701</p>	 <p>Ref : 314582 Presser bar lifter Singer 4538-4552-4562-4572-5910-7028-9005-9008-9010-9030-9034-9044-9134-9410-9416-93220 077.314.582</p>
 <p>Ref : 356170-451 Presser bar lifter Singer 2440-2502-2503-2504-2505-2515-2517-2530-2543-2732-2950-3270-3314-3317-3343-5050-5417-5430-5825-5830-5838-57825-CM17-DX14-FM17-SM14 077.356.170</p>	 <p>Ref : 381947 Presser bar lifter Singer 900-920-925-935U-1030-1036-2000-2001-2005-2010 077.381.947</p>	 <p>Ref : 386137 Presser bar lifter Singer Quantum XL100, Quantum XL150, Quantum XL1000 077.386.137</p>
 <p>Ref : 387502 Presser bar lifter Singer Quantum XL5000 077.387.502</p>	 <p>Ref : 396014-76 = 396010-85 Presser bar lifter Elna 604E, 614DE, 624DS, 624DSE, 704DEX, 744, 745, 845, 904DCX, 905DCX, 925DCX, 945, PRO4DC, PRO4DE, PRO5DC & PRO5DE 077.396.076</p>	 <p>Ref : 411461-10 Presser bar lifter Elna Star 31-33-41-64-72-74-62 077.411.461</p>
 <p>Ref : 4115546-02 Presser bar lifter Husqvarna 6680, 6690, 6440, 6450 077.411.554</p>	 <p>Ref : 4121502-01 Presser bar lifter Husqvarna 1200, #1 077.412.150</p>	 <p>Ref : 4123097-02 Presser bar lifter Husqvarna 215-225-230-234-250-300-310-315-320-325-330-335-340-341-350-400-530-540-550-555-560-600-605 (Rose) 078.412.309</p>
 <p>Ref : 4125725-01 Presser bar lifter with spring Husqvarna 215-225-230-234-250-300-310-315-320-325-330-335-340-341-350-400-530-540-550-555-560-600-605 (Rose) 077.412.572</p>	 <p>Ref : 412787-100 = 412787-003, 410354 Presser bar lifter Singer 14U32A-14U34B-14U44-14U46B-14U64A-14U65B-14U85B-14U234-14U234B-14U285-14U286-14U344-14U354-14U354B-14U444-14U444B-14U454-14U454B-PRO4D 077.412.787</p>	 <p>Ref : 418420-10 Presser bar lifter Elna Carina Jubilee 45, Star 62-64-72-74, Stella 22-27-37-57 077.418.420</p>
 <p>Ref : 4311040-01 Presser bar lifter Husqvarna 2800 077.431.104</p>	 <p>Ref : 44445 Presser bar lifter Singer 241-247-263-249-288-290-290C-547-563-588-2404-3101-3102-3103-3105-6100-6102-6104-6105-6106-6110-6112-6114-6115-6116-6120-6122-6124-6125-6126-6130-6136-6146-6152-6156-6174-6184-9502-9505-9518-9602-9606-9608-9610-9612-9614-9618-9605 077.044.445</p>	

PODIZA I STOPICE - LEVIER PIED DE BICHE - PRESSER BAR LIFTER - HEBEL

 <p>Ref : 461200-10 Presser bar lifter Elna 6000, 7000, 8000</p> <p>077.461.200</p>	 <p>Ref : 461210-10 Presser bar lifter Elna 9000</p> <p>077.461.210</p>	 <p>Ref : 502024001 = 395743-43 Presser bar lifter Elna 3230 Janome 4119, 6019, 6125, 6260</p> <p>077.502.024</p>
 <p>Ref : 502362 Presser bar lifter Singer 1425U, 1411U</p> <p>077.502.362</p>	 <p>Ref : 503607007 Lifter plate unit Janome 6019, 6260, 6125</p> <p>077.503.607</p>	 <p>Ref : 6473 Presser bar lifter White 8000</p> <p>077.006.473</p>
 <p>Ref : 650032015 Presser bar lifter Elna 664 Janome 134D, 204D, 504D, 634D, 734D, 1110DX, 8002D, 9102D, CoverPro 900CP, CoverPro 1000CP Kenmore 385.1664190, 385.16642090, 385.16644690, 385.1788180</p> <p>077.650.032</p>	 <p>Ref : 652145007 Presser bar lifter Elna 3002, 3004, 3006 Janome 462, 4618LE, 5024, 5124, MS3015 Kenmore 385.1782480</p> <p>077.652.145</p>	 <p>Ref : 6659 Presser bar lifter White 80, 162</p> <p>077.006.659</p>
 <p>Ref : 6691 Presser bar lifter White 7000, 221</p> <p>077.006.691</p>	 <p>Ref : 72209 Presser bar lifter White 734DW</p> <p>077.072.209</p>	 <p>Ref : 730119 Presser bar lifter Babylock BL66, BL67 (Audrey) Singer 117, 2623 White 2999</p> <p>077.730.119</p>
 <p>Ref : 735029004 = 395726-07 Presser bar lifter Babylock BL18, BL18A (Natalie), BL20A (Anna), BL30A (Molly) Elna 1000 (Sew Fun), 2600 Janome 1810, 3000, 3500, 4000, 4400, 4800, 8077, DC3018, DC3050, HF2022, JP760 (Jem Platinum 760) Kenmore 385.19112, 385.1168291</p> <p>077.735.029</p>	 <p>Ref : 75273 Presser bar lifter Singer 132Q</p> <p>077.075.273</p>	 <p>Ref : 7616 Presser bar lifter White 7234</p> <p>077.007.616</p>
 <p>Ref : 76443 Presser bar lifter Juki HZL-35Z Singer 2638, 2639, 2662</p> <p>077.076.443</p>	 <p>Ref : 7698 Presser bar lifter White 1405, 1407</p> <p>077.007.698</p>	 <p>Ref : 79025 Presser bar lifter Singer 14J334 White 2000</p> <p>077.079.025</p>
 <p>Ref : 822071004 Presser bar lifter Janome 4612, MC5500, TB12</p> <p>077.822.071</p>	 <p>Ref : 830035012 Presser bar lifter Elna 9500 Janome MC300E, MC5700, MC8000, MC9000, MC9500, MC9700, MC11000</p> <p>077.830.035</p>	 <p>Ref : 93-030658-41 Presser bar lifter Pfaff 280, 290, 800</p> <p>077.030.658</p>
 <p>Ref : 93-037190-71 Presser bar lifter Pfaff 1475</p> <p>077.037.190</p>	 <p>Ref : 93-039130-44 Presser bar lifter Pfaff 2140</p> <p>077.039.130</p>	 <p>Ref : 93-040191-41 Presser bar lifter Pfaff 1212, 1213, 1214, 1216, 1217, 1222, 1229</p> <p>077.040.191</p>
 <p>Ref : C5465-01A-05 Presser bar lifter Babylock BL101</p> <p>077.546.501</p>	 <p>Ref : E1A0173000 Presser bar lifter lever Singer 3810, 3812, 30820, 3825, 6510, 6550, 7350</p> <p>077.017.300</p>	 <p>Ref : V10333000 Presser bar lifter Singer 1105, 1106, 1107, 1120, 1130, 1525, 8770</p> <p>077.103.330</p>
 <p>Ref : X51943151 Presser foot lifter Babylock BL1556, BL2160, BL6200, BL2100, BL6000, BL2150, BL6700 Brother XL4010, XL4020, XL4030, XL4050, XL4060, XL4040, PS1000, PS1250, PS1700, PS1750, PS1800, PS1900, PS1950, PS2100, XL2010, XL2015, XL2021, XL2022, XL2025, XL2030, XL3010, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XR29, XR31, XR33, XR34, XR35, XR37, XR40, XR23, VX1100, VX1200</p> <p>077.051.943</p>	 <p>Ref : X56051001 Presser bar lifter Babylock BL9500, ESI, ESI2 Brother PC5000-PC6000-PC7000-PC7500-PC8000-PC8895</p> <p>077.056.051</p>	

PODIZA I STOPICE - LEVIER PIED DE BICHE - PRESSER BAR LIFTER - HEBEL

 <p>Ref : X57848051 Presser bar lifter Babylock BL500A (Jane), BLQP Brother PQ1300, PQ1500 077.057.848</p>	 <p>Ref : X58677051 Presser bar lifter Babylock BL60E-EAC-EM1- EM2-SE1-SE2-SE3 Bernina Deco 500-Deco 600 Brother PE100-PE150- PE180D-PE200 077.058.677</p>	 <p>Ref : X76597001 Presser bar lifter Brother PL2100 Husqvarna 1001LCD, 1003LCD White 1001LCD 077.076.597</p>			
 <p>Ref : X77625-001 Presser bar lifter Brother 925D, 929D, 935D 077.077.625</p>	 <p>Ref : XA1868151 = XA1868051 Presser bar lifter Babylock ESE-ESE2-ESL- ESP (Espire) Brother PC6500-PC8200- PC8500 077.001.868</p>	 <p>Ref : XA5156151 Presser foot lifter Brother PE300S, PE400D 077.005.156</p>			
 <p>Ref : XA2511151 = XA2511121 Presser foot lifter Babylock B15, B17, B21 Brother JS-23, LS-1217, LS-1520, LS-2125, LS-2125b, LS-2125i, LS-2129, LS-2130, LS-2150, LS-2160, LS-2220, LS-2720, LS-2725, LS- 2820, LS-2825, LS-2920, LX-3125, LX-3125e, RS15, RS25, RS35, SL-7, VX1120, VX1125, VX1140, PX100, PX150, PX200, PX300, VX- 1435, X-5, XL5000, XL5010, XL5011, XL5012, XL5020, XL5021, XL5022, XL5030, XL5031, XL5032, XL5050, XL5060, XL5070, XL5100, XL5130, XL5200, XL5232, XL5300, XL5340, XL5500, XL5600, XL5700, XL6040, XL6050, XL6060, XL6452, XL6562, XR46, XR52C, XR65T 077.025.111</p>					
 <p>Ref : XA5511151 Presser bar lifter Babylock ESG-ESG2-ESG3 Brother PC2800-PC3000- ULT2001-ULT2002D- ULT2003D 077.005.511</p>	 <p>Ref : XA6941001 Knee lifter Babylock ESG-ESG2- ESG3 Brother ULT2001- ULT2002D-ULT2003D 077.006.941</p>	 <p>Ref : XB0878-001 Presser bar lifter Brother 1034D 077.000.878</p>			
 <p>Ref : B5165-02A-33 Presser bar lifter Babylock BLE8 (Evolve) 077.516.502</p>	 <p>Ref : R1A0213000 Presser bar lifter Babylock BLQ2 Singer Quantum L-500 077.213.000</p>	 <p>Ref : XC4902021 Presser bar lifter Babylock BL40, BL40A (Grace) Brother BM2600, BM3500, CE-4000, CE-5000PRW, CP-7500, CS-770, CS- 6000, ES-2000, Innov-is 40 (NS40), L25, L35, LS-590, SQ-9000, XL2120, XL2121, XL2130, XL2140, XL2150, XL2220, XL2230, XL2240, XL2250, XL2600, XL2610, XL2620, XL3500, XL3500T, XL3510, XL3520, XL3800 077.049.020</p>			
 <p>Ref : 21406103 Presser bar lifter Juki DNU-1541, LS-1342, LU-1508N, LU-1510N, LU- 1520N, LU-1560N, LU- 1565N 077.214.061</p>	 <p>Ref : A1510E80000 Presser bar lifter Juki HZL-E80 077.151.080</p>	 <p>Ref : A1512090000 Presser bar lifter Juki TL-98E, TL-98Q, TL- 98QE, TL-98P 077.151.209</p>			
 <p>Ref : 301069009 Presser bar lifter Necchi 3101FA, 3102FB, 3204FB, 3205FA White 1418, 1477, 1866 077.301.069</p>	 <p>Ref : 610109009 Presser bar lifter Necchi 3832, 3832FA 077.610.109</p>	 <p>Ref : 735029200 Presser bar lifter Necchi 6150 077.735.030</p>			
 <p>Ref : H10663001 Presser bar lifter Necchi 4575 077.106.630</p>	 <p>Ref : 93-036198-15 Presser bar lifter Pfaff 6250, 1475, 875 077.036.198</p>	 <p>Ref : 370154006 Presser bar lifter White 1760XL, 1888, 2360 077.370.154</p>			
 <p>Ref : 87806 Presser bar lifter Singer 7256, 8763, 8780 (Curvy) 077.087.806</p>	 <p>Ref : F4A0043000 Presser bar lifter Husqvarna E20 Husqkystar Singer 1732, 2932, 3116 077.004.300</p>	 <p>Ref : 87297 Presser bar lifter Singer 7436, 7463, 7467, 7469, 7469Q 077.087.297</p>			
<p>Ref : 730119030 Presser bar lifter White 2037 077.730.119</p>	<p>Ref : 556197-391 Presser bar lifter Singer 14CG744, 14CG754, 14SH744, 14SH754 077.556.197</p>	<p>Ref : G1298 Presser bar lifter Singer 14T957DC, 14T968DC 077.001.298</p>	<p>Ref : PFW-45910 Presser bar lifter Singer 221 Featherweight 077.045.910</p>	<p>Ref : V880153000 Presser bar lifter Singer 2263 (Simple) 077.880.153</p>	<p>Ref : 4117494-01 Presser bar lifter Husqvarna 150, 160, 180, 185, 190 077.411.749</p>