





















## TEFLONSKJE STOPICE - TEFLONVOETEN - PIEDS TEFLON - FEET TEFLON - TEFLONFÜßE

 <p><b>Ref : TN 50 = P60516</b> Roller foot high With slide ring Hoog/haut</p> <p><b>071.310.710</b></p>	 <p><b>Ref : PD5011-20=5011-20=SA122</b> Teflon foot (SS), snap-o-matic Brother CE4000, CE5000PRW, CS100T, ES2000, LS1717, LS2125, LS2125i, PS3700, VX1400, VX1435, XL3022, XL3025, XL3027, XL3030, XL3100, XL3200, XL3500, XL5130, XL5232, XL5340, XL6562, XR37</p> <p><b>077.501.126</b></p>	 <p><b>Ref : 941310000 = 1189A</b> Straight stitch foot Teflon low Laag/bas</p> <p><b>077.941.310</b></p>
 <p><b>Ref : 941320000</b> Straight stitch foot Teflon high Hoog/haut</p> <p><b>077.941.320</b></p>	 <p><b>Ref : 941330000</b> Straight stitch foot Teflon slant Schuin/oblique</p> <p><b>077.941.330</b></p>	 <p><b>Ref : 93-036917-91</b> Teflon foot, snap-on Pfaff 1006-7570</p> <p><b>077.036.917</b></p>
 <p><b>Ref : 283427</b> Teflon foot Singer Quantum CXL, LE, XL1</p> <p><b>077.283.427</b></p>	 <p><b>Ref : 386029</b> Decorative stitch foot Singer Quantum XL1000</p> <p><b>077.386.029</b></p>	 <p><b>Ref : 388041</b> Teflon foot Singer Quantum XL5000, 6000</p> <p><b>077.388.041</b></p>
 <p><b>Ref : 941270000 = 1195A</b> Zigzag foot Low teflon Laag/bas</p> <p><b>077.941.270</b></p>	 <p><b>Ref : 941280000</b> Zigzag foot High teflon Hoog/haut</p> <p><b>077.941.280</b></p>	 <p><b>Ref : 941290000</b> Teflon foot, slant shank Schuin/oblique Singer</p> <p><b>077.941.290</b></p>
 <p><b>Ref : P40324</b> Zipper foot, slant shank teflon Singer</p> <p><b>077.040.324</b></p>	 <p><b>Ref : XC1949002</b> Snap-on teflon foot 7mm. Brother-Singer-Babylock- Elna</p> <p><b>077.194.902</b></p>	 <p><b>Ref : 4127961-45</b> Teflon foot Husqvarna</p> <p><b>077.412.796</b></p>
 <p><b>Ref : 161166T</b> Zipper foot, slant shank teflon Singer</p> <p><b>077.161.166</b></p>	 <p><b>Ref : 551T</b> Zipper foot low, 3 to 1 teflon</p> <p><b>078.000.551</b></p>	 <p><b>Ref : 552T</b> Zipper foot high, 3 to 1 teflon</p> <p><b>078.000.552</b></p>
 <p><b>Ref : 553T</b> Zipper foot slant, 3 to 1 teflon</p> <p><b>078.000.553</b></p>	 <p><b>Ref : 55632T</b> Zipper foot, high teflon hinge</p> <p><b>078.055.632</b></p>	

## KOMPEZACIJSKE STOPICE - LAAG MODEL / PIEDS COMPENSE TEFLON - BAS

<u>1 mm</u>	<u>1,5 mm</u>	<u>2,4 mm</u>	<u>3 mm</u>	<u>4 mm</u>	<u>5 mm</u>	<u>6 mm</u>	<u>zig zag 5 mm</u>
							
FA/N1,0 077.020.000	FA/N1,5 077.020.001	FA/N2,4 077.020.002	FA/N3,0 077.020.003	FA/N4,0 077.020.004	FA/N5,0 077.020.005	FA/N6,0 077.020.006	FA/ZZ-5 077.020.007