

## STOPICE ZA SKRIVENI PORUB - PIEDS OURLET INVISIBLE - FEET BLINDSTITCH - BLINDSTICH FÜßE



**Ref : 0025807000** Blindstitch foot #5  
Bernina 530-532-534-540-600-610-640 (not  
Artist 640)-642-644-700-707-708-709-717-  
718-719-730 (not Artist 730)-731-732-740-  
741-742-744-800-801-802-803-807-808-809  
-810-811-817-818-819-830-831-832-840-  
841-842-850-900-910-930-931-932-940-950  
-1000-1001-1004-1005-1006-1008-1010-  
1011-1015-1020-1030-1031-1080-1090-  
1120-1130-1230-1260-1530-1630  
**077.002.580**



**Ref : 156 SN = 10402** Blindhem foot, slant shank  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628,  
629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714,  
717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775,  
776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001,  
2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019,  
9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9123, 9133, 9135, 9137, 9143,  
9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**077.000.158**



**Ref : 10402 P** Blindhem foot, slant shank  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628,  
629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714,  
717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775,  
776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001,  
2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019,  
9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9123, 9133, 9135, 9137, 9143,  
9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**078.010.403**



**Ref : 820817015 = 395719-35** Blindhem foot  
Babylock BL20A (Anna)  
Janome Décor Excel 5018, Décor Excel Pro  
5124, MC3000, MC3500, MC4800QC,  
MC4900QC, MC5700, MC6500, MC6600,  
MC6600P, MC9000, MC9500, DC3018,  
MC10000, MC10001, MC11000, 4618, 4623,  
5024, 6019QC, 6125QC, DC3050, Jem Gold 2,  
Jem Platinum 720, Jem Platinum 760  
Kenmore 158.13570, 385.1654200,  
385.162213, 385.19000  
Necchi 6150  
**077.820.817**



**Ref : X56409001 = XE2650001, X56409051, X56409-001** Blindhem foot  
Babylock BL40, BL40A (Grace), BL200A (Elizabeth),  
BLCC (Crafter's Choice), BLCC2 (Crafter's Choice),  
BLDC, BLDC2 (Decorator's Choice), BLG, BLMY  
(Melody), BLN (Esante), BLOC, BLR3 & BLTP  
(Tempo), ESP, ES12, ESE, ESE2, ESG, ESL, ESN  
(Encore), ESP (Espire), INT  
Brother CS8060, CS8100, CS8150, CS8200,  
NV1200, NV4000D, NX200, NX400, NX600,  
PC7000, PC7500, PC8000, PC8200, PC8500,  
PC8895, PE300S, PE400D, ULT2001, ULT2002,  
ULT2003D  
**077.056.409**



**Ref : XC1957002 = SA133** Blindhem foot  
Babylock ESE, ESE2, ESG  
Brother PC8200-PC8500-  
SE270D-ULT2001-  
ULT2002  
**077.195.700**



**Ref : 30218** Blindhem foot  
Babylock BL8800  
Elna 300-1500-1600-Top  
300  
Riccar REC6000  
**077.030.218**



**Ref : 425822** Blindhem foot  
Elna  
**077.425.822**



**Ref : 494480-20** Foot blindhem  
Elna 8000-9000-DIVA  
**077.494.480**



**Ref : X75524-001** Foot blindhem  
Brother 526, 546D, 626D, 634D,  
730DE, 760DE, 834DP, 934D,  
PL1500, PL1600, PL2000, 526D,  
546, 920D, PL1050, 640D, 925D,  
935D, 929D, 1034D  
Husqvarna S800, S900, 535D,  
560ED  
**077.075.524**



**Ref : 93-037903-91** Blindhem foot  
Pfaff all models 1006-7570  
(no IDT)  
**077.037.903**



**Ref : R9** Foot blindhem  
Riccar snap-on  
**077.200.009**



**Ref : 006812008** Foot blindhem  
Singer 1105-1116-1120-  
1130-1507-1525-1732-2250-  
2259-2263-2932-3116-4423-  
6510-7312-7322-7350-7358-  
7422-7424-7426-8280  
**077.681.208**



**Ref : 10400-L=156L** Blindhem foot  
Singer low  
**077.000.156**



**Ref : 10402-S** Blindhem foot, slant shank  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628,  
629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714,  
717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775,  
776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001,  
2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019,  
9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9123, 9133, 9135, 9137, 9143,  
9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**077.000.158**



**Ref : 283402** Blindhem foot  
Singer Quantum CXL,  
LE, XL1  
**077.283.402**



**Ref : 386016** Blindhem foot  
Singer Quantum XL100,  
XL150, XL1000  
**077.386.016**



**Ref : 388033** Blindhem foot  
Singer Quantum XL5000,  
Quantum XL6000  
**077.388.033**



**Ref : 77049** Blindhem foot  
Juki HZL-25Z  
Singer 132Q, 140Q  
**077.077.049**



**Ref : HP30218-3** Blindhem foot  
Singer 9910, 9920, 9940  
**077.302.183**



**Ref : 156 L = 10400** Blindhem foot, low shank  
**077.000.156**



**Ref : 156 H = 10401** Blindhem foot, high shank  
Babylock BLQP  
Brother PQ1300-PQ1500-PQ1500S  
Janome 1600P-1600PDB-  
1600PDBX-MC6600  
Juki DDL8700-TL98E-TL98Q-  
TL98QE-TL98P  
Pfaff 1200 Grand Quilter  
**077.000.157**



**Ref : PD5011-7 =129868001** Blindhem foot, snap-on  
Babylock BL7000, BL7500,  
BL8000, BL8500, BL9500  
Brother 845, PC5000,  
PC6500  
**077.501.110**



**Ref : 006904008 = 357990, 76255** Blindhem foot  
Singer 4206-4212-4220-4228-4411-  
6510-7312-7322-7350-7358-7422-  
7424-7426-7463-7469-7469Q-7470-  
8763 Curvy-8780 Curvy-CE100-  
CE150-CE200-CE250-CE350-  
SES1000-SES2000  
White 3100  
**077.690.408**



**Ref : 98-694890-00 = 820256096** Foot blindstitch  
Pfaff 3.0, 4.0, 933, 939, 955, 1006, 1007,  
1050 - 1171, 1371, 1467, 1471, 1530,  
1536, 1538, 1540, 1546, 1548, 2020,  
2030, 2040, 2024, 2026, 2028, 2034,  
2036, 2042, 2044, 2046, 2124, 6091,  
6122, 6152, 6232, 6250, 6270, 7560,  
6000 Series  
**077.694.890**



**Ref : 4115331-45** Foot blindstitch  
Husqvarna "D" FT  
**077.411.533**



**Ref : 4129766-45** Foot blindstitch  
Husqvarna  
**077.412.976**

**STOPICE ZA SKRIVENI PORUB - PIEDS OURLET INVISIBLE - FEET BLINDSTITCH - BLINDSTICH FÜßE**

**Ref : 825817009** Blindhem foot  
Janome MC3000, MC3500,  
Décor Excel 5018, Décor Excel  
Pro 5124, MC5700, MC6500,  
MC9000, DC3018, MC6600,  
MC4800QC, MC4900QC,  
MC10001, MC11000, 4618,  
4623, 6260QC, DC3050  
**077.825.817**



**Ref : 385099**  
Blindhem foot  
Singer Quantum LE-SX-  
SX100-XL5000-XL6000  
**077.385.099**



**Ref : PD5011-7**  
Blindhem foot, snp-on  
**077.501.110**



**Ref : 356630**  
Blindstitch foot  
Singer 241, 247, 263, 288, 547, 563, 588, 2001, 2302, 2303, 2304, 2315, 2330, 2404,  
2440, 2502, 2503, 2504, 2515, 2530, 3101, 3102, 3103, 3105, 3314, 3317, 3343,  
4205, 4210, 5705, 5812, 5814, 5816, 5818, 5825, 5830, 5838, 6221, 9134, 9850,  
9852, 9855, 9858, 6860, 9867, 9876, 57825, CG590, CM17, FM22, HD105, HD110  
**077.356.630**