

## STOPICE - PERSVOETEN - PIEDS PRESSEUR - PRESSER FEET - PRESSERFÜßE **SINGER**

 <p><b>Ref : 76838</b> Foot 1/4" Singer 132Q, 140Q</p> <p><b>077.076.838</b></p>	 <p><b>Ref : 77046</b> Foot zipper Singer 132Q, 140Q</p> <p><b>077.077.046</b></p>	 <p><b>Ref : 77051</b> Foot open toe Singer 132Q, 140Q</p> <p><b>077.077.051</b></p>
 <p><b>Ref : 79498</b> Foot straight stitch Singer 118</p> <p><b>077.079.498</b></p>	 <p><b>Ref : XC1949002</b> Snap-on 7mm. teflon foot Brother, Singer, Babylock, Elna</p> <p><b>077.194.902</b></p>	 <p><b>Ref : P60804</b> 1/4" foot, snap-on</p> <p><b>077.060.804</b></p>
 <p><b>Ref : P60963</b> Felling foot, snap-on, 4mm.</p> <p><b>077.060.963</b></p>	 <p><b>Ref : P60973</b> Felling foot, snap-on, 6mm.</p> <p><b>077.060.973</b></p>	 <p><b>Ref : 730167</b> Zigzag foot Singer 117</p> <p><b>077.730.167</b></p>
 <p><b>Ref : 76250</b> Presser foot shank Singer 118-2638-2639- 2662-6518-7256-7258</p> <p><b>077.076.250</b></p>	 <p><b>Ref : 76251</b> Zigzag presser foot Singer 2009 (Athena), 2638, 2639, 2662, 6518, 7256, 7258, 7422, 7424, 7426, 7430, 7436, 7442, 7444, 7446, 7462, 7463, 7464, 7466, 7468, 7469, 7470, 8763 Curvy, 8780 Curvy</p> <p><b>077.076.251</b></p>	 <p><b>Ref : 76259</b> Hemmer foot Singer 2662-2638-7258</p> <p><b>077.076.259</b></p>
 <p><b>Ref : 76360</b> Buttonhole foot Singer 2638-2639-2662</p> <p><b>077.076.360</b></p>	 <p><b>Ref : 77045</b> Zigzag foot Singer 132Q-140Q</p> <p><b>077.077.045</b></p>	 <p><b>Ref : 77047</b> Sliding buttonhole foot Juki HZL-25Z Singer 132Q-140Q</p> <p><b>077.077.047</b></p>
 <p><b>Ref : 77048</b> Roller foot Singer 132Q-140Q</p> <p><b>077.077.048</b></p>	 <p><b>Ref : 77049</b> Blindhem foot Juki HZL-25Z Singer 132Q-140Q</p> <p><b>077.077.049</b></p>	 <p><b>Ref : 77050</b> Rollhem foot Singer 132Q-140Q</p> <p><b>077.077.050</b></p>
 <p><b>Ref : 77068</b> Presser foot shank Singer 132Q-140Q</p> <p><b>077.077.068</b></p>	 <p><b>Ref : 79497</b> Overcast foot Singer 118</p> <p><b>077.079.497</b></p>	

## BIEZENVOETEN - PIEDS NERVURE - PINTUCKING FEET - BIESEN FÜßE



**Ref : 212-32019 = 701L**  
Pintuck foot  
Low shank  
7 grooves  
Kenmore 385  
**077.212.320**



**Ref : 701S** Pintuck foot - Slant shank - 7 grooves  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628, 629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714, 717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775, 776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001, 2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9032, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**077.701.000**



**Ref : 107-32019 = 701H**  
Pintuck foot - High shank - 7 grooves  
Babylock BLQP  
Brother PQ1300-PQ1500-PQ1500S  
Janome 1600P-1600P/DB-1600P/  
DBX-MC6600  
Juki TL98Q-TL98QE-TL98E  
Pfaff 1200 Grand Quilter  
Husqvarna Mega Quilter  
**077.107.320**



**Ref : P60805**  
Pintuck foot  
Low shank  
5 deep grooves  
**077.060.805**



**Ref : PD5011-15**  
Pintuck foot  
Plate snap-on  
5 grooves  
**077.501.121**



**Ref : P60807** Pintuck foot - Slant shank - 5 grooves  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628, 629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714, 717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775, 776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001, 2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9032, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**078.060.807**



**Ref : P60815**  
Pintuck foot metal  
Low shank  
7 grooves  
**077.060.815**



**Ref : P60817** Pintuck foot - Slant shank - 7 grooves  
Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628, 629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714, 717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775, 776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001, 2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9032, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**077.060.817**



**Ref : S701L**  
Pintuck foot low  
Snap-on  
**077.000.701**



**Ref : P60810**  
Pintuck foot plastic  
Low shank  
7 grooves  
**077.060.810**



**Ref : P60812** Pintuck foot plastic - Slant shank - 7 grooves  
266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628, 629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 649, 700, 706, 708, 714, 717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775, 776, 778, 784, 786, 900-3, 920-3, 1000, 1036, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001, 2010, 4552, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9032, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444  
**077.060.812**



**Ref : S701S**  
Pintuck foot  
Slant shank  
**077.000.702**



**Ref : P60818**  
Pintuck foot metal  
Low shank  
9 grooves  
**077.060.818**



**Ref : P60819**  
Pintuck foot metal  
Slant shank  
9 grooves  
**077.060.819**



**Ref : 200009108**  
Pintuck foot - Snap-on - 5 grooves  
Using twin needles, sew evenly spaced pintucks on light to medium weight fabrics. Perfect for corded pintucks using pintuck cord guide.  
Janome Jem Gold 660, MC3000, MC3500, Decor Excel 5018, Decor Excel Pro 5124, MC5700, MC10000, MC6500, MC9000, DC3018, MC6600, MC4800QC, MC4900QC, 4618, 4623, 6019QC, 6125QC, 6260QC, DC3050, Jem Gold 2, Jem Platinum 720, Jem Platinum 760, MC10001, MC9500, MC9700  
**077.009.108**



**Ref : 200005104**  
Pintuck foot - Snap-on - 7 grooves  
Using twin needles, sew evenly spaced pintucks on soft, lightweight fabrics.  
Janome MC3000, MC3500, Decor Excel 5018, Decor Excel Pro 5124, MC5700, MC10000, MC6500, MC9000, DC3018, MC11000, MC6600, MC4800QC, MC4900QC, 4618, 4623, 6019QC, 6125QC, 6260QC, DC3050, MC10001, MC9500, MC9700  
**077.005.104**



**Ref : 386022**  
Pintuck foot  
Singer Quantum LE-XL10-XL100-XL150-XL5000-XL6000  
7 grooves  
**077.386.022**



**Ref : 494580-20**  
Pintuck foot  
5 grooves  
Elna 8000, 9000, Diva  
**077.494.580**



**Ref : 426850**  
Pintuck foot, snap-on  
5 grooves, 5mm.  
**077.426.850**



**Ref : P60416**  
Pintuck foot, snap-on, 7mm, 7 grooves  
Babylock ESE, ESE2, ESG Ellageo, ESG2, ESG3  
Brother NX200, NX400, NX600, PC2800, PC3000, PC5000, PC6000, PC6500, PC7000, PC7500, PC8000, PC8200, PC8500, ULT2001, ULT2002, ULT2003  
Elna 8000, 9000  
Singer 3709, 6510, 7350  
**077.060.416**



**Ref : 4123699-45**  
Pintuck foot  
5 grooves  
Husqvarna  
**077.412.699**



**Ref : 4123700-45**  
Pintuck foot  
9 grooves  
Husqvarna  
**077.412.702**



**Ref : 4123628-45**  
Pintuck foot 7mm.  
Husqvarna  
**077.412.362**



**Ref : 93-042950-91**  
Pintuck foot  
5 grooves  
Pfaff 933-939-955-1006-1007-1050/1171-1371-1467-1471-6091-6000 series  
**077.042.950**



**Ref : 93-042953-91**  
Pintuck foot  
7 grooves  
Pfaff 933-939-955-1006-1007-1050/1171-1371-1467-1471-6091-6000 series  
**077.042.953**

**GOVI**

)UDQMH 5D NRJ


**COMPANY d.o.o.**

5,-(. \$ WHO














ID[

PDLO JRYLF FRPSDQ\#LQHV

## STOPICE - PIEDS PRESSEUR CLIC CLAC - PRESSER FEET - PRESSERFÜßE SINGER SNAP-ON

 <p><b>Ref : 006916008</b> Foot straight stitch Singer 2250-2259-2263-3116-3709-3722-3810-3812-4423-7322 White 3100 <b>077.691.608</b></p>	 <p><b>Ref : 006900008</b> Hemmer foot Brother SE350 Singer 2009-6510-72567312-7322-7350-7358-7422-7424-7426-7436-7442-7444-7446-746-7463-7464-7466-7468-7469-7469Q-8768-SES1000 <b>077.690.008</b></p>	 <p><b>Ref : 006910008</b> Foot shank Singer 1105-1116-1120-1130-1507-1525-1732-1748-2250-2259-2263-2273-2932-3116-3709-3722-3810-3820-3825-3860-6038-6510-6550-7312-7322-7350-7360-7380-7464-7466-8280-8770 <b>077.691.008</b></p>
 <p><b>Ref : 006914008</b> Foot button Singer 1105-1116-1120-1130-1525-1732-2250-2259-2263-2932-3116-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.691.408</b></p>	 <p><b>Ref : 006905008</b> Foot zipper Singer 1105-1116-1120-1130-1525-1732-2250-2259-2263-2273-2932-3116-4206-4212-4220-4228-6510-7312-7322-7350-7358-7422-7424-7426-7442-7463-7469-7469Q-7470-8280-8763 Curvy-8780 Curvy-CE100-CE150-CE200-CE250-CE350-SES1000-SES2000 <b>077.690.508</b></p>	 <p><b>Ref : 006904008</b> Blindhem foot Singer 4206-4212-4220-4228-4411-6510-7312-7322-7350-7358-7422-7424-7426-7463-7469-7469Q-7470-8763 Curvy-8780 Curvy-CE100-CE150-CE200-CE250-CE350-SES1000-SES2000 <b>077.690.408</b></p>
 <p><b>Ref : 006174008</b> Foot buttonhole Singer 6510-7312 <b>077.061.748</b></p>	 <p><b>Ref : 006917008</b> Foot gathering Singer 1732-3116-4423 Heavy Duty-6510-7312-7322-7350-7358 <b>077.006.917</b></p>	 <p><b>Ref : 006813008</b> Foot cording Singer 1100-2623-2638-3800-6038-6510-7300-7312-7322-7350-7358-7460-9900-CE100-CE200-CXL-XL1-XL100-XL1000-XL5000-XL6000 <b>077.681.308</b></p>
 <p><b>Ref : 006918008</b> Foot ZZ Singer 3820-6510-6550-7312-7322-7350-7358 <b>077.691.808</b></p>	 <p><b>Ref : 006907008</b> Overcasting foot Singer 6510-7312-7322-7350-7358 <b>077.006.907</b></p>	 <p><b>Ref : 006812008</b> Foot blindhem Singer 1105-1116-1120-1130-1507-1525-1732-2250-2259-2263-2932-3116-4423-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.681.208</b></p>
 <p><b>Ref : 006806008</b> Foot ZZ Singer 1105-1106-1120-1130-1507-1732-1748-2250-2259-2263-2273-2932-4220-4228-6038-8770 <b>077.680.608</b></p>	 <p><b>Ref : 006803008</b> Foot overcast Singer 1105-1116-1120-1130-1525-1732-2250-2259-2263-2932-3116-4423-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.680.308</b></p>	 <p><b>Ref : 006800008</b> Foot hemmer Singer 1105-1116-1120-1130-1525-1732-2250-2259-2263-2932-3116-4423-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.680.008</b></p>
 <p><b>Ref : 006810008</b> Foot cording Singer 1105-1116-1120-1130-1525-2932-3116 Simple-4423-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.681.008</b></p>	 <p><b>Ref : 006804008</b> Foot satin Singer 1105-1116-1120-1130-1525-1732-2250-2259-2263-2932-3116-4423-6510-7312-7322-7350-7358-7422-7424-7426-8280 <b>077.680.408</b></p>	 <p><b>Ref : 006172008</b> Satin stitch foot Singer 3709, 3722 <b>077.617.208</b></p>
 <p><b>Ref : 006171008</b> Foot buttonhole Singer 3116 Simple-3810-3820-3822-7350 <b>077.061.718</b></p>	 <p><b>Ref : 006909008</b> Foot buttonhole Singer 1105-1116-1120-1130-1525-2250-2259-2263-8280 <b>077.069.908</b></p>	 <p><b>Ref : 321417008</b> Straight stitch foot Singer 117 <b>077.321.417</b></p>
 <p><b>Ref : P60415</b> Roller foot snap-on Babylock ESE, ESE2, ESG Ellageo, ESG2, ESG3 Brother NX200, NX400, NX600, PC2800, PC3000, PC5000, PC6000, PC6500, PC7000, PC7500, PC8000, PC8200, PC8500, ULT2001, ULT2002, ULT2003 Elna 8000, 9000 Singer 3709, 6510, 7350 <b>077.060.415</b></p>		
 <p><b>Ref : P60416</b> Pintuck foot 7G, snap-on Babylock ESE, ESE2, ESG Ellageo, ESG2, ESG3 Brother NX200, NX400, NX600, PC2800, PC3000, PC5000, PC6000, PC6500, PC7000, PC7500, PC8000, PC8200, PC8500, ULT2001, ULT2002, ULT2003 Elna 8000, 9000 Singer 3709, 6510, 7350 <b>077.060.416</b></p>		

## STOPICE - PIEDS PRESSEUR - PRESSER FEET - PRESSERFÜßE SINGER 9910-9920-9940

 <p><b>Ref : HP30244</b> Foot overcast Singer 9910/20/40</p> <p><b>077.030.244</b></p>	 <p><b>Ref : HP11117</b> Foot quilting guide Singer 9910/20/40</p> <p><b>077.011.117</b></p>	 <p><b>Ref : HP12928</b> Foot buttonhole Singer sew on 9910/20/40</p> <p><b>077.012.928</b></p>
 <p><b>Ref : HP30686</b> Foot cording Singer 9910/20/40</p> <p><b>077.030.686</b></p>	 <p><b>Ref : HP31461</b> 1/4" foot Singer 9910, 9920, 9940</p> <p><b>077.031.461</b></p>	 <p><b>Ref : HP33069</b> Foot open toe Singer 9410/20/40</p> <p><b>077.033.069</b></p>
 <p><b>Ref : PD5011-7</b> <b>=HP30218-3</b> Foot blindhem Singer 9910/20/40</p> <p><b>077.302.183</b></p>	 <p><b>Ref : HP30685</b> Foot hemmer Singer 9410/20/40</p> <p><b>077.030.685</b></p>	 <p><b>Ref : HP31093</b> Foot buttonhole Singer XL3400</p> <p><b>077.031.093</b></p>
 <p><b>Ref : HP32969</b> Foot ZZ Singer 9410/20/40</p> <p><b>077.032.969</b></p>	 <p><b>Ref : HP30057</b> Zigzag foot Singer 9410/20/40 Singer Quantum XL3400</p> <p><b>078.030.057</b></p>	 <p><b>Ref : HP32948</b> Foot buttonhole Singer 9410-9420-9440</p> <p><b>077.032.948</b></p>
 <p><b>Ref : HP32968</b> Presser foot shank Singer 9410-9420-9440</p> <p><b>077.032.968</b></p>		

