














SUPORT - RALLONGE PIED (SUPPORT PIED) - FOOT ADAPTOR SHANK - NÄHFUßHALTER

 <p>Ref : 12502 Shank White 299D-8234-S34-S34D 077.012.502</p>	 <p>Ref : 141000223 Shank White 2000 077.141.223</p>	 <p>Ref : 141000371 Shank White 1500 077.141.371</p>
 <p>Ref : 98-694581-00 Presser foot shank Pfaff 1197-1211-1212-1213-1214-1216-1217-1222-1222E-1229 077.694.581</p>	 <p>Ref : 98-694886-00 Presser foot shank Pfaff 933-939-955-1006-1007-1050-1067-1069-1071-1147-1151-1171-1371-1467-1471-1472-1473-1475-2030-4240-4250-4260-6085-6091-6110-6120-6130-6150-6230-6250-6270-7000-7510-7530-7550-7570 077.694.886</p>	 <p>Ref : RO Foot shank Riccar 077.200.000</p>
 <p>Ref : 387505 Shank Singer Quantum XL5000-Quantum XL6000 077.387.505</p>	 <p>Ref : 416105 Shank Singer 117 Babylock BL66-BL67 077.416.105</p>	 <p>Ref : 76250 Presser foot shank Singer 118-2638-2639-2662-6518-7256 077.076.250</p>
 <p>Ref : 446014-1 = 155964-00, 155964, 155964000, 155964-851, 155964-892 Presser foot shank Elna SU 96 Singer 237, 241, 247, 252, 257, 258, 263, 288, 328, 337, 338, 353, 360, 362, 413, 416, 418, 457, 476, 478, 513, 518, 533, 534, 543, 547, 563, 588, 802, 807, 809, 813, 814, 818, 822, 824, 827, 833, 834, 838, 844, 1021, 1022, 1482, 1485, 1486, 1488, 1490, 1492, 2102, 2105, 2106, 2108, 2110, 2112, 2114, 2118, 2210, 2302, 2303, 2304, 2315, 2330, 2404, 2440, 2502, 2503, 2504, 2505, 2515, 2517, 2530, 2543, 2732, 3101, 3102, 3103, 3105, 3270, 3314, 3317, 3343, 4205, 4210, 4325, 4528, 4530, 4552, 4622, 4830, 5017, 5028, 5040, 5050, 5107, 5405, 5417C, 5430, 5430C, 5502, 5504, 5505, 5508, 5522, 5524, 5525, 5528, 5705, 5710, 57817, 57820, 57825, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5828, 5830, 5838, 5932, 6100, 6102, 6104, 6105, 6106, 6110, 6120, 6130, 6136, 6146, 6152, 6156, 6174, 6184, 6210, 6211, 6212, 6214, 6215, 6217, 6221, 6233, 6234, 6235, 6408, 6412, 6416, 6423, 6544, 6620, 7028, 7037, 7136, 7146, 7184, 7186, 7211, 7212, 8734, 9005, 9008, 9010, 9022, 9110, 9113, 9117, 9124, 9410, 9420, 9423, 9432, 9444, 9502, 9505, 9518, 9602, 9605, 9606, 9608, 9610, 9612, 9614, 9618, 9850, 9852, 9855, 9858, 6860, 9867, 9876, CG500, CG550, CG590, CM17, DX14, FM17, FM22, HD102, HD105, HD110, SM14 077.446.015</p>		
 <p>Ref : 542167 = 163706-000, 163706451, 163706-451 Presser foot slant shank Singer 266, 290, 301, 401, 411, 431, 500, 501, 502, 503, 503A, 600, 603, 604, 610, 625, 626, 628, 629, 630, 631, 635, 635E3, 635E6, 635E7, 636, 638, 639, 640, 645, 646, 648, 649, 700, 706, 708, 714, 717, 719, 720, 721, 724, 725, 729, 734, 737, 740, 746, 750, 755, 756, 758, 760, 766, 770, 774, 775, 776, 778, 784, 786, 900-3, 920-3, 1000 Futura, 1036, 1030, 1050, 1100, 1410, 1411, 1425, 2000, 2000A, 2001, 2010, 4552, 4562, 4610, 4622, 5910 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9032, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9334, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440, 9444 077.542.167</p>	 <p>Ref : 77068 Presser foot shank Singer 132Q-140Q 077.077.068</p>	
 <p>Ref : HP13235 Presser foot shank Singer Quantum XL3400 077.013.235</p>	 <p>Ref : HP32968 Shank Singer 9410-9420-9440 077.032.968</p>	 <p>Ref : 5011-1 Snap-on shank, low shank 077.100.001</p>
 <p>Ref : 5011-2 Presser foot shank, high shank 077.100.002</p>	 <p>Ref : PD5011-58 Plastic low shank 077.501.104</p>	 <p>Ref : PD5011-60 Plastic snap-on shank, slant 077.501.105</p>
 <p>Ref : 006910008 Presser foot shank Singer 1105-1116-1120-1130-1507-1525-1732-1748-2250-2259-2263-2273-2932-3116-3709-3722-3810-3820-3825-3860-6038-6510-6550-7312-7322-7350-7360-7380-7464-7466-8280-8770 077.691.008</p>	 <p>Ref : 4111400-01 Presser foot shank Husqvarna all models 2000-6690 incl. 1010-1030-1040-3240-3610-4100-4300-4500-4700-5610-5710-6030-6430-6440-6460-6570-6690 077.411.140</p>	 <p>Ref : 4117445-01 Presser foot shank Husqvarna 990S-990-980-960-950S-950-945-940-1250-#1-#1+-1200-1100-1090-1070-1070S-1050 White 9800 077.411.744</p>
 <p>Ref : 4126161-45 Presser foot shank Husqvarna 077.412.616</p>	 <p>Ref : FHL Adaptor foot high-low For low feet to high feet 077.010.003</p>	 <p>Ref : 85016 Shank Singer 7422-7424-7426-7436-7442-7444-7446-7462-7464-7466-7468-CE100 Quantum Futura-CE200 Futura 077.085.016</p>
 <p>Ref : 283102 Shank Singer DSX-Quantum CXL-Quantum XL1-Quantum XL50 077.283.102</p>	 <p>Ref : 385042 Shank Singer SL100/150-Quantum LE/SX/SX100/XL100/XL1000/XL150 077.385.042</p>	 <p>Ref : 4124112-01 = 4124112-45 = 4124112 Presser foot shank Husqvarna 077.412.411</p>

SUPPORT - RALLONGE PIED (SUPPORT PIED) - FOOT ADAPTOR SHANK - NÄHFUßHALTER

 <p>Ref : B5001S01A Foot shank Babylock BLE1</p> <p>077.500.101</p>	 <p>Ref : 138881-001 Foot shank Brother 546-546D-626D-634D-834DP</p> <p>077.138.881</p>	 <p>Ref : 0060827300 Shank Bernina 125-200</p> <p>077.608.273</p>
 <p>Ref : 446014 Foot shank, 3 set low zigzag, straight stitch</p> <p>077.446.014</p>	 <p>Ref : B5001S05A Foot shank Babylock BLE1-BLE8</p> <p>078.500.105</p>	 <p>Ref : XA3808001 Presser foot shank Babylock ESE Brother PC8200</p> <p>077.380.801</p>
 <p>Ref : XA4789001 Presser foot shank Babylock ESE-ESE2-ESL-ESG-ESG2 Brother ULT2001-ULT2002-PE8500</p> <p>077.478.901</p>	 <p>Ref : XA6023001 Shank adaptor Babylock ESE Brother PC8200-ULT2003D</p> <p>077.602.300</p>	 <p>Ref : XA6027001 Foot shank adaptor Babylock ESE Brother PC8500-ULT2001-ULT2002</p> <p>077.602.701</p>
 <p>Ref : XC2242051 Shank Babylock ESG3 Brother ULT2003D</p> <p>077.224.205</p>	 <p>Ref : XC3015051 = XA8970051, 129855001 Presser foot shank Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BL2100, BL2150, BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY (Melody), BLQC, BLSO (Ellisimo), BLG (Ellegante), BLG2 (Ellegante 2), BLTP (Tempo), ESN (Encore), ESP (Espire), INT (Intrigue) Brother CE-4000, CE-5000PRW, CE-5500, CE-5500PRW, CP-6500, CP-7500, CS-770, CS-6000, CS-8060, CS-8072, CS-8100, CS-8150, CS-8200, DS-120, DS-140, ES-2000, EX-660, FS-20, FS-40, FS-40WT, HE-240, HS-2500, Innovis 40 (NS40), LB-6800PRW, LS-2125i, LS-2130, LS-2150, LX-3125, LX-3125e, PC-210, PC-210PRW, PC-4000, PC-5000, PC-6000, PC-8000, PE-300S, PE-400D, PS-1700, PS-1750, NV2500D, NV-4000D, NX-200, NX-400, NX-600, SE-270D, SE-350, SE-400, SQ-9000, XL3750, XL-6040, XL-6050, XL-6060, XL-6452, XL-6562, XR-46, XR-52T, XR-65T, XR-4040, XR-7700</p> <p>077.301.505</p>	
 <p>Ref : 494150 = 425620 Presser foot shank low Elna, all models</p> <p>077.494.150</p>	 <p>Ref : 804509000 = 395714.17 Presser foot shank, low Elna 3003, 3005, 3007, 6001, 6003, 6004, 7002 Janome 5124, 6260, CE2200, MC3500, MC5500, MC5700, MC6000, MC7500, MS3015 (All Janome 2000 - 7500) Kenmore 385.162213, 385.1764180, 385.17822490, 385.18230, 385.18836, 385.1884180 Necchi 6150 Husqvarna 224</p> <p>077.804.509</p>	 <p>Ref : 823509000 Shank Kenmore 385 top load</p> <p>077.823.509</p>
 <p>Ref : 830038004 = 395717.86 Shank Elna 8006-9006-CE20 Janome MC5000-MC5700-MC6600-MC8000-MC9000-MC10000 Kenmore 385.190000-385.19000690</p> <p>077.830.038</p>	 <p>Ref : A1514-776-OCO = A1514-535-OCO Shank Bernina 2000DCE-2000DE Bernette 003-004-MO334-MO334D-MO334DS Juki MO634-634DE-MO644D-MO654DE</p> <p>077.514.776</p>	 <p>Ref : X77862-001 Presser foot shank Brother 925D-935D-3034D</p> <p>077.077.862</p>
 <p>Ref : XB0311-001 Shank Brother 929D-1034D</p> <p>077.031.001</p>	 <p>Ref : 396010-92 Shank Elna 604E-614DE-624DSE</p> <p>078.396.010</p>	 <p>Ref : A1502-134-OBO Presser foot shank Juki MO134</p> <p>077.502.134</p>
 <p>Ref : 787541008 Presser foot shank Elna 664 Janome 134D-204D-534-534D-634D-734D-1110DX-3434D-9102D Pfaff 752-4752</p> <p>077.787.541</p>	 <p>Ref : 550305 Presser foot shank Pfaff 4762-4772 Singer 14U555-14U554-14U544</p> <p>077.550.305</p>	 <p>Ref : A1A021004 Foot shank Singer 14T948DS-14T957DC-14T967DC-14T968DC</p> <p>077.021.004</p>
 <p>Ref : 60807 = 784501007 = 330525 = 340567 Presser foot shank snap-on Babylock BL302-BL400-BL5040-BL5040L Pfaff 774-776-783-784-786-787-788-794-795-796-797-799-4860-4870 Riccar RL624-RL624E-RL634E-RL634DE Singer 14U594-14U595</p> <p>077.060.807</p>	 <p>Ref : 411000052 Shank Husqvarna 905-910-935</p> <p>078.411.052</p>	

SUPPORT - RALLONGE PIED (SUPPORT PIED) - FOOT ADAPTOR SHANK - NÄHFUßHALTER

 <p>Ref : 0083687000 Houder voor fronsapparaat <i>Support pour fronceur</i> Ruffler adaptor Bernina 100-190 077.008.368</p>	 <p>Ref : 0019477000 Foot adaptor Bernina 077.001.947</p>	 <p>Ref : 0019857000 Houder voor fronsapparaat <i>Support pour fronceur</i> Ruffler adaptor Bernina 077.001.985</p>
 <p>Ref : 0062617000 Shank adaptor snap-on Bernina 530-530/2-531-532-532/2-534-540-540/2-542/2-600-610-614-640/2-642/2-644-700-707-708-709-717-718-719-730-731-732-741-742-744-800-801-801S-802-802S-803-803S-807-808-809-810-811-811s-817-818-819-830-830E-830H-831-832-840-841-842-850-900-900E-910-910N-930-931-932-940-950-1000-1001-1004-1005-1006-1008-1010-1011-1020-1030-1031-1080-1090-1120-1130-1230-1260-1530-1630 077.006.261</p>	 <p>Ref : 0083677000 Foot adaptor Bernina 100-190 077.836.770</p>	
 <p>Ref : 91-006603-22/00 Shank Pfaff HOOG/HAUTHIGH 083.025.801</p>	 <p>Ref : 91-006603-22/11 Shank Pfaff 138/238-34/134/234 LAAG/BAS/LOW 083.025.800</p>	 <p>Ref : 772936 Shank Singer 807 Refrey 427/430 077.772.936</p>
 <p>Ref : 395710-01 = 611510000 Shank Babylock BL18-BL23 Elna 2002-2004-2006 Janome 1004-1508 077.395.710</p>	 <p>Ref : 129855001 = XC3015051, XA8970051 Presser foot shank Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BL2100, BL2150, BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Decorator's Choice), BLMY (Melody), BLQC, BLSO (Ellisimo), BLG (Ellegante), BLG2 (Ellegante 2), BLTP (Tempo), ESN (Encore), ESP (Espire), INT (Intrigue) Brother CE-4000, CE-5000PRW, CE-5500, CE-5500PRW, CP-6500, CP-7500, CS-770, CS-6000, CS-8060, CS-8072, CS-8100, CS-8150, CS-8200, DS-120, DS-140, ES-2000, EX-660, FS-20, FS-40, FS-40WT, HE-240, HS-2500, Innovis 40 (NS40), LB-6800PRW, LS-2125i, LS-2130, LS-2150, LX-3125, LX-3125e, PC-210, PC-210PRW, PC-4000, PC-5000, PC-6000, PC-8000, PE-300S, PE-400D, PS-1700, PS-1750, NV2500D, NV-4000D, NX-200, NX-400, NX-600, SE-270D, SE-350, SE-400, SQ-9000, XL3750, XL-6040, XL-6050, XL-6060, XL-6452, XL-6562, XR-46, XR-52T, XR-65T, XR-4040, XR-7700 077.129.855</p>	

VRSTE STOPICA TYPE VOETEN - TYPE DE PIED PRESSEUR - TYPE FEET - TYPE FÜSSE

