

TJERAČI PETLJAČA - DRIJVERS - CHASSE NAVETTE - SHUTTLE DRIVERS - TREIBER



Ref : 0026537000
Shuttle driver Bernina
1004-1015, 1020-1530

077.002.653



Ref : 141000143
Hook drive shaft comp.
White 1477, 1488

077.141.143



Ref : 4116415-01
Shuttle driver
Viking 5610, 5710, 6030-
6690

077.411.641



Ref : 2441
Shuttle driver
Singer 15-30/86/96/97

085.002.441



Ref : 30701
Shuttle driver side load
(for Z13A)

077.030.701



Ref : 0026537101
Shuttle driver
Bernina 730-932

077.002.654



Ref : JO1310
Shuttle driver HA-1

077.001.310



Ref : X54429051
Shuttle driver
Brother-VX1100, VX1200,
XL2010-2030, XL3010-
3200,
XL4010-4060

077.054.429



Ref : X56665051
Shuttle driver
Brother VX520-1020

077.056.665



Ref : XA1021051
Shuttle driver
Brother VX1120/25/40,
XL5010-5700

077.010.210

Ref : 0017205200
Screw shuttle driv.
spring mounting Bernina
730-1530 for 002653700

077.001.720

Ref : 137805051
Hook washer
Brother 895, PC5000,
PC6000

077.137.805

Ref : J1654
Screw race cap spring
(F/1803) front load

077.001.654



Ref : 155883
Pin carrier
Singer 514/8/34/38

077.155.883



Ref : 45761
Hook loop guard
Singer 221

077.045.761



Ref : 2533
Spring race back
Singer 15-30, 15-88/90

077.002.533



Ref : 313155
Spring hook drive
Singer 4613/17/23, 4663,
6234/5, 6267/8, 6250/1,
9113/17/24, 9217/24/40

077.313.155



Ref : 54507
Shuttle carrier
Singer 27, 127CL

077.154.507



Ref : J1653
Screw shuttle driver
spring (F/JO1310A)
Singer 15, 66 CL

077.001.653



Ref : 627191000
Hook plate bottom
New Home 5124

077.627.191



Ref : 2531
Race cover
Singer 15-30/86/88/96/97
F/2528

077.002.531



Ref : 170160
Hook gib
Singer 221, 301

077.170.160



Ref : 4123065-01
Magnet hook
Viking S230-S500

078.412.306



Ref : 317.015.233
Hook gib
Bernina 840/50, 940/50
(2 screw hole)

077.317.015



Ref : 317.027.032
Hook gib
Bernina 840/50, 940/50
(no screw hole)

077.317.027