

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **BABYLOCK** - HANDWHEELS - HANDRÄDER

 <p>Ref : 137694002 Handwheel Babylock BL7500, BL8000, BL8500 Brother 845 077.137.694</p>	 <p>Ref : X59289051 Handwheel Babylock BL1556-BL2160-BL6200 Brother XL4010-XL4020-XL4030- XL4050-XL4060-XL4040-PS1000- PS1250-PS1800-XL3010-XL3022- XL3025-XL3027-XL3030-XL3100- XL3200-XR31-XR33-XR34-XR35- XR37-XR40 077.592.890</p>	 <p>Ref : X57370022 Handwheel Babylock BL6300-BL6800 Brother PS53-PS55-PS57- PS2250-PS2360-PS2470- PS3100-PS3700-XL6040- XL6050-XL6060-XL6452- XL65262-XR46-XR52C-XR65- XR65T 077.057.372</p>
 <p>Ref : 61255-B Handwheel Babylock BL402 Simplicity SL390 077.061.255</p>	 <p>Ref : H13513211 Handwheel Babylock BL3000-BL4000- BL5000 Necchi 4575-4595-4795 Riccar R550-R650-R750- RM540 077.135.132</p>	 <p>Ref : 168013-010 Handwheel Babylock BL66-BL67 (Audrey) Singer 117 White 1740 077.168.013</p>
<p>Ref : R1A1703210 Handwheel Babylock BLQ2 Singer Quantum L500 077.170.321</p>		

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **BERNINA** - HANDWHEELS - HANDRÄDER

 <p>Ref : 0031535000 Handwheel Bernina 1004, 1008 077.315.350</p>	 <p>Ref : 305.318.03 Handwheel Bernina 910 077.305.318</p>	 <p>Ref : X75202-001 Handwheel Bernina 800 Husqvarna S900-560ED Brother 730DE-760DE- PL1500-PL2000-PL1600 077.075.202</p>

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **ELNA** - HANDWHEELS - HANDRÄDER

 <p>Ref : 396203-97 = 60164 Elna T33, T34, L3 Simplicity SL804D 077.396.203</p>	 <p>Ref : 735608302 Elna 2002-2004-2006 Janome 1506-1508-1518 -1612-1622-1814-1818- 1822 078.735.608</p>	

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **RICCAR** - HANDWHEELS - HANDRÄDER

 <p>Ref : H13513211 Handwheel Babylock BL3000-BL4000- BL5000 Necchi 4575-4595-4795 Riccar R550-R650-R750- RM540 077.135.132</p>	 <p>Ref : 138635004 Handwheel Brother 7029-PS1200-VX920 -VX940-VX950-VX970- VX980-VX1010-VX1020- SL9130-SL9150-SL9240 Riccar R1950 077.138.636</p>	


ZAMAŠNJACI - HANDWIELEN - VOLANTS - **BROTHER** - HANDWHEELS - HANDRÄDER

 <p>Ref : 138635001 Handwheel Brother VX800-VX807- VX809-VX810-VX880- VX890 077.138.635</p>	 <p>Ref : 138635004 Handwheel Brother 7029-PS1200-VX920- VX940-VX950-VX970-VX980- VX1010-VX1020-SL9130- SL9150-SL9240 Riccarr R1950 077.138.636</p>	 <p>Ref : 138652055 Stop motion knob Brother 7029-PS1200-VX800 -VX807-VX809-VX810- VX880-VX890-VX920-VX940 -VX950-VX970-VX980- VX1010-VX1020 077.138.652</p>
 <p>Ref : X54360051 Handwheel Brother XL2010-XL2015- XL2021-XL2022-XL2025- XL2030-XR29- XR23 077.543.600</p>	 <p>Ref : X54361051 Stop motion knob Brother XL2010-XL2015- XL2021-XL2022-XL2025- XL2030-XR29- XR23- VX1100-VX1200 077.054.361</p>	 <p>Ref : X57370051 = X59879051 Balance Wheel Babylock BL6200-BL6700- BL7800-ESL-ESN (Encore)- ESE2-ESP (Espire) Brother CL8072-PC3000- PC6500-PS1250-PS1950- PS2500 077.057.370</p>
 <p>Ref : X75202-001 Handwheel Bernina 800 Husqvarna S900-560ED Brother 730DE-760DE- PL1500-PL2000-PL1600 077.075.202</p>	 <p>Ref : X77603-001 Timing pulley Brother 925D-935D-929D- 1034D 077.077.603</p>	 <p>Ref : XC2375051 Handwheel Babylock BL40, BL40A (Grace), BL137A2 (Sofia 2), BL200A (Elizabeth), BLMY (Melody), BLCC (Crafter's Choice), BLCC2 (Crafter's Choice), BLDC, BLDC2 (Crafter's Choice), BLTP (Tempo) Brother HE-240, Innov-is 40 (NS40), LB- 6770, LB-6800PRW, NX-400, NX-600, NV- 900, NV-900D, NV-1000, SE-350 & SE- 400 077.002.375</p>
 <p>Ref : 137694002 Handwheel Babylock BL7500, BL8000, BL8500 Brother 845 077.137.694</p>	 <p>Ref : X59289051 Handwheel Babylock BL1556-BL2160-BL6200 Brother XL4010-XL4020-XL4030- XL4050-XL4060-XL4040-PS1000- PS1250-PS1800-XL3010-XL3022- XL3025-XL3027-XL3030-XL3100- XL3200-XR31-XR33-XR34-XR35- XR37-XR40 077.592.890</p>	 <p>Ref : X57370022 Handwheel Babylock BL6300-BL6800 Brother PS53-PS55-PS57- PS2250-PS2360-PS2470- PS3100-PS3700-XL6040- XL6050-XL6060-XL6452- XL65262-XR46-XR52C-XR65- XR65T 077.057.372</p>
<p>Ref : XC7772051 Handwheel Babylock BLN (Esante) Brother NV1500D- NV2500D-NV4000D 077.007.772</p>	<p>Ref : XA9418001 Handwheel Babylock ESG-ESG2- ESG3 Brother ULT2001- ULT2002D-ULT2003D 077.009.418</p>	

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **HUSQVARNA** - HANDWHEELS - HANDRÄDER

 <p>Ref : 4117050-01 Handwheel Husqvarna 100-110-120- 140-150-160-185-190 077.411.050</p>	 <p>Ref : 4117986-01 Pin handwheel Husqvarna 940-950-960- 980-990 077.411.798</p>	 <p>Ref : 4120047-01 Handwheel extra Husqvarna 078.412.004</p>
 <p>Ref : 4122222-03 Handwheel Husqvarna 940-950-960- 980-990 077.412.222</p>	 <p>Ref : 4123009-01 Viking 205-210-215-230- 250-310-315-320-325-330- 335-350-400-415-425-500- 535-545-555-Anna-Juliet- Romeo-Sarah 077.412.300</p>	 <p>Ref : X75202-001 Handwheel Bernina 800 Husqvarna S900-560ED Brother 730DE-760DE- PL1500-PL2000-PL1600 077.075.202</p>

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **NECCHI** - HANDWHEELS - HANDRÄDER

 <p>Ref : H13513211 Handwheel Babylock BL3000-BL4000- BL5000 Necchi 4575-4595-4795 Riccarr R550-R650-R750- RM540 077.135.132</p>	<p>Ref : 653061115 Handwheel Janome 5018-5124-8080LX200- DC3018-DC3050-MC3500-MC4800 Kenmore 385.19001890- 385.19030790-385.19153690- 385.19365990 Necchi 6150 077.653.061</p>	
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

ZAMAŠNJACI - HANDWIELEN - VOLANTS - JANOME - HANDWHEELS - HANDRÄDER



Ref : 735608302
= 395711-68
Elna 2002-2004-2006
Janome 1506-1508-1518-
1612-1622-1814-1818-
1822
078.735.608



Ref : 820514008
Janome 5001
077.820.514



Ref : 650064407
Janome 2015-2022-5500
077.650.064



Ref : 825088003
Janome MC7000-
MC7500
077.825.088



Ref : 653058005
Janome MC4023-4123-
5000-Decor Excel Pro 5124
-2200-CE2200-MC4000-
MC8000-MC9000
077.653.058



Ref : 784019003
Janome 203-303-234-
235D-334-334D-Mylock
134D
077.784.019



Ref : 803621109
Janome S750
077.803.621




Ref : 650609503
Janome Schoolmate
S3015-3023-3123-
4618LE
077.650.609



Ref : 787175007
= 98-787175-00/700
Janome 434-434D-534D-
634D
Pfaff 752-4752
077.787.175

ZAMAŠNJACI - HANDWIELEN - VOLANTS - PFAFF - HANDWHEELS - HANDRÄDER



Ref : 29-924993-81/267
Handwheel
Pfaff 4874
077.925.015



Ref : 403083
Handwheel
Pfaff 4240-4250-4260
Singer 1019-1025-1027
077.403.083



Ref : 93-035107-75
Handwheel
Pfaff 1006-1007-1010-1037-
1047-1051-1067-1069-1071-
1147-1151-1171-1371-1467-
1469-7510-7530-7550-7560-
7570
077.035.107



Ref : 93-037214-44
Handwheel
Pfaff 7560
077.037.214



Ref : 93-038129-44
Handwheel
Pfaff 2010-2020-2030-
2040-2140
077.038.129



Ref : 93-040115-55
Handwheel
Pfaff 1197-1211-1212-
1213-1214-1216-1217-
1222-1229
077.040.115



Ref : 98-735608-106
Handwheel
Pfaff 342-380-382
077.735.608



Ref : 93-040226-45
Handwheel catch
Pfaff
077.040.226



Ref : 93-034116-25
Handwheel screw
Pfaff 1000-1006-1007-1010-
1027-1037-1047-1051-1067-
1069-1071-1147-1151-1171-
1200-1213-1214-1216-1217-
1222
077.034.116





























Ref : 93-0401655-BL
Handwheel screw
Pfaff 1100-1200-1222
077.401.655



Ref : FF11267
Handwheel
Pfaff 4862-4872
077.011.267

ZAMAŠNJACI - HANDWIELEN - VOLANTS - SINGER - HANDWHEELS - HANDRÄDER

 <p>Ref : 074212 Handwheel Singer 100 077.074.212</p>	 <p>Ref : 125458 = 125355 Handwheel with spring Singer 15-91, 201-2 077.125.458</p>	 <p>Ref : 137159-451 Handwheel Singer 6408-6412-6423-6416 077.137.159</p>
 <p>Ref : 168013-010 Handwheel Babylock BL66-BL67 (Audrey) Singer 117 White 1740 077.168.013</p>	 <p>Ref : 283589 Handwheel Singer Quantum CXL, Quantum XL10, Quantum XL50 077.283.589</p>	 <p>Ref : 286831-001 Handwheel Singer 4617-4623-6234-6235-6267-6268-9113-9114-9124-9133-9137-9143-9217-9224-9240 077.286.831</p>
 <p>Ref : 316070-001 = 313185-453 Handwheel clutch Singer 4552-4562-4572-4610-4622-5910-6233-7028-9005-9008-9010-9015-9018-9020-9022-9027-9030-9032-9034-9044-9110-9130-9210-9408-9410-9416-9420-9423-9430-9432-9444-30518-93220 077.313.185</p>	 <p>Ref : 357009-451 = 446386-451 Handwheel =prima Singer 714-4325-4522-4525-4526-4528-4530-4538-4620-4825-4828-4830-4832-5017-5028-5040-5050-5605-5610-5705-5710-5812-5814-5816-5818-5825-5830-5838-6012-6201-6212-6217-6620-7025-7101-7102-7104-7105-7106-7108-7110-7136-7171-7174-7211-7212-8220-9936-57817-57817C-57820-57825-717 School-7100-7114-7180-9506-9802-9803-9805-9808-9810-9812-9814-9816-9818-9818-9824-9828-9832-9836-9936-57825-CG500-CG550-CG590-CM17-CP17-FM17-FM19-FM22-SM14 077.357.009</p>	
 <p>Ref : 357009-453 = 446386 Handwheel Singer CG500-CG550-CG590 077.357.009</p>	 <p>Ref : 357395-451 Handwheel Singer 2440-2502-2503-2504-2505-2515-2517-2530-2543-3270-3314-3317-3343-DX14 077.357.395</p>	 <p>Ref : 357737-001 Handwheel with clutch Singer 2950-5417-5430 077.357.737</p>
 <p>Ref : 359104-001 Handwheel Singer 2712-2718-2722-2724-2730-2732 077.359.104</p>	 <p>Ref : 385025 Handwheel Singer Quantum DSX, DSX II, LE, SX, SX100 077.385.025</p>	 <p>Ref : 386100 Handwheel Singer Quantum XL100, Quantum XL150, Quantum XL1000 077.386.100</p>
 <p>Ref : 387458 Handwheel Singer Quantum XL5000 077.387.458</p>	 <p>Ref : 410268-004 = 410268-002 Handwheel Singer 14U234, 14U234B, 14U344, 14U354 078.410.268</p>	 <p>Ref : 76748 Handwheel Singer 132Q-140Q 077.076.748</p>
 <p>Ref : 868025-001 Handwheel Singer 2623 077.868.025</p>	 <p>Ref : E1A0073210 Handwheel Singer 3709-3722-3810-3820-3825-6510-6550-7312-7322-7350-7380 077.073.210</p>	 <p>Ref : V10183210 Handwheel Singer 1107-1105-1116-1120-1130-1525 077.101.832</p>
 <p>Ref : 172312 Handwheel gear Singer 401-401A-600-603-604-620-625-629-630-635-639-645-646-648E-649-750-755-756-758 077.172.312</p>	 <p>Ref : 382320 Handwheel pulley Singer 900-3, 920-3, 925, 1200, 2000 077.382.320</p>	 <p>Ref : 403083 Handwheel Pfaff 4240-4250-4260 Singer 1019-1025-1027 077.403.083</p>
 <p>Ref : 364290-900 Handwheel Singer 14CG744, 14CG754, 14SH744, 14SH754 077.364.290</p>	 <p>Ref : 410368-004 Handwheel Singer 14U344, 14U354 077.410.368</p>	 <p>Ref : E1A0073209 Handwheel Singer 3116 Simple 077.073.209</p>
<p>Ref : 87299 Handwheel Singer 7256-7442-7462-7463-8763 077.087.299</p>	<p>Ref : A11401567 Handwheel Singer 14T957DC, 14T967DC 077.114.015</p>	<p>Ref : 83050 Handwheel Singer CE150-CE250-CE350-SES1000 077.083.050</p>

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **SINGER** - HANDWHEELS - HANDRÄDER

	<p>Ref : PFW-45817 Handwheel Singer 221 Featherweight</p> <p>077.045.817</p>	<p>Ref : V6E0233210 Handwheel Singer 2250, 2263 (Simple)</p> <p>077.233.210</p>	 <p>Ref : 357367-901 Clutch plate cover for 357009-451 Singer 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4620, 4825, 4828, 4830, 5017, 5028, 5040, 5605, 5610, 5705, 5710, 6201, 6217, 6620, 7025, 7211, 7212, 8220, 9936, 57817, 57820, 57825, 9802-9836, FM17, FM19, FM22, CG500, CG550, CG590</p> <p>077.357.367</p>
<p>Ref : 546826 Handwheel Singer 20U</p> <p>077.546.826</p>	 <p>Ref : HP32833 Handwheel Singer 9910-9920-9940</p> <p>077.032.833</p>		

ZAMAŠNJACI - HANDWIELEN - VOLANTS - **WHITE** - HANDWHEELS - HANDRÄDER

	<p>Ref : 0076051 Handwheel White 3300</p> <p>077.076.051</p>	 <p>Ref : 11941 Handwheel White 7234-7934DW</p> <p>077.011.941</p>	 <p>Ref : 1350013105650 Handwheel White 4041</p> <p>077.135.131</p>
	<p>Ref : 0076051 Handwheel White 3300</p> <p>077.076.051</p>	 <p>Ref : 141000020 Handwheel White 1477</p> <p>077.141.020</p>	 <p>Ref : 141000370 Handwheel White 1500</p> <p>077.141.370</p>
	<p>Ref : 141000703 Handwheel White 1911</p> <p>077.141.703</p>	 <p>Ref : 141000749 Handwheel White 970-979</p> <p>077.141.749</p>	 <p>Ref : 2141003151651 Handwheel White 905-910-936</p> <p>077.214.100</p>
	<p>Ref : 301540098 Handwheel White 144-1755</p> <p>077.301.540</p>	 <p>Ref : 30540009 Handwheel White 1477-1488</p> <p>077.305.400</p>	 <p>Ref : 6696 Handwheel White 221-7000</p> <p>077.006.696</p>
	<p>Ref : 673211 Handwheel White 2235</p> <p>077.673.211</p>	 <p>Ref : 7115 Handwheel White 1588</p> <p>077.007.115</p>	 <p>Ref : 7163 Handwheel White ET6-ET10</p> <p>077.007.163</p>
	<p>Ref : 868025004 Handwheel White 2037-2999</p> <p>078.868.025</p>	 <p>Ref : FF11267 Handwheel White 4862-4872</p> <p>077.011.267</p>	 <p>Ref : 168013-010 Handwheel Babylock BL66-BL67 (Audrey) Singer 117 White 1740</p> <p>077.168.013</p>